



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	339	6222A 8	SWITCH BOX ASSEMBLY	1		
2	10	45218	SCREW, SWITCH BOX GROUND	1		
3	10	22523	SCREW, SWITCH BOX (3/4")	2		
3A	23	26731	SPACER, SWITCH BOX SCREW (2		
4	12	56681	WASHER, SWITCH BOX SCREW	2		
5	54	63153	"J" CLIP, SWITCH BOX LEAD	1		
6	84	76223 8	WIRE, HIGH TENSION	2		
6	33	72983	SPARK PLUG (USE IN BELGIUM	2		
7	33	48370	SPARK PLUG (USE IN UNITED S	2		
8	339	5288A 2	IGNITION COIL ASSEMBLY	2		
10	11	45076	NUT, IGNITION COIL TERMINAL	4		
11		76254	COIL COVER	2		
12	10	76502	SCREW, COIL COVER (1 7/8")	6		
13		61990	STA-STRAP, SWITCH BOX LEAD:	1		
14		57908 2	SLEEVE, SWITCH BOX LEADS	2		