



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1427	3263A	1 CLAMP BRACKET ASSEMBLY	2		
2		22477A	1 THUMB SCREW ASSEMBLY	2		
3		26227	1 WASHER, THUMB SCREW	2		
4	17	49930A	1 TILT LOCK PIN ASSEMBLY	1		
5	23	59623	1 SPACER, CLAMP BRACKET STUD	1		
6	16	59625	1 STUD, CLAMP BRACKET	1		
7	11	28770	2 NUT, CLAMP BRACKET STUD	2		
8		30664	1 TUBE, TILT - CLAMP BRACKET T	1		
9	12	52864	6 WASHER, CLAMP BRACKET TO S	6		
10	11	30499	2 NUT, TILT TUBE	2		
11		52882A	1 STEERING ARM AND SWIVEL PII	1		
11		52882A	2 STEERING ARM AND SWIVEL PII	1		
12		30711	1 BUMPER, STEERING ARM	1		
13	10	33986	2 SCREW, UPPER MOUNT TO STE	2		
14		34255	1 BUMPER, STEERING ARM	1		
15		39503	1 BRACKET, REMOTE STEERING	1		
16	16	39781	2 STUD, REMOTE STEERING BRA	2		
17	11	20509	2 NUT, REMOTE STEERING BRACI	2		
18	10	31830	1 SCREW, RIDE-GUIDE KIT TO STE	1		
19	11	20509	1 NUT, RIDE-GUIDE KIT SCREW	1		
20	12	52865	1 WASHER, SWIVEL PIN	1		
21	38	56267	1 SERIAL PLATE	1		
22	10	25612	4 SCREW, DRIVE - SERIAL PLATE	4		
23	10	26483	2 BOLT, CLAMP BRACKET TO BOA	2		
24	12	26485	2 WASHER, CLAMP BRACKET BOL	2		
25	11	26484	2 NUT, CLAMP BRACKET BOLT	2		
26		53078	2 CAP, PLASTIC - TILT TUBE	2		
27		56349	1 SHAFT, REVERSE LOCK TO SWP	1		
28	17	25598	1 ROLL PIN, REVERSE LOCK SPRII	1		
29		26903A	1 REVERSE LOCK ASSEMBLY	1	SERIAL 00000000-02979678	
29		39015A	1 REVERSE LOCK ASSEMBLY	1	SERIAL 03043031-09999999	
30	24	29821	1 SPRING, REVERSE LOCK TENSIO	1		
31	18	45882	1 COTTER PIN, REVERSE LOCK TC	1		
32		47912A	2 LEVER ASSEMBLY, TILT STOP -	1		
33	1455	4514A	1 SWIVEL BRACKET ASSEMBLY (S	1		
33	1462	4515A	1 SWIVEL BRACKET ASSEMBLY (L	1		
34	26	32911	2 OIL SEAL, SWIVEL BRACKET	2		
35	22	23612	1 FITTING, GREASE - SWIVEL BF	1		
36		29359	1 LUBRICAP, SWIVEL BRACKET GF	1		
37	12	25176	1 WASHER, SWIVEL PIN TO BOTT	1		
37	12	26927	1 WASHER, SWIVEL PIN TO BOTT	1		