



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1352	3967	CARBURETOR ASSEMBLY, COM	1	SERIAL 00000000-02979678	
1	1352	4511A 1	CARBURETOR ASSEMBLY, COM	1	SERIAL 03043031-09999999	
2	1399	110A 1	FLOAT ASSEMBLY	1		
3			PIN, FLOAT LEVER PINION	2		3
4			LEVER, FLOAT (LOWER)	1		3
5			LEVER, FLOAT (UPPER)	1		3
6	1399	1473	INLET NEEDLE, SEAT AND GA	1	SERIAL 00000000-02979678	3
6	1395	4555	INLET NEEDLE, SEAT AND GA	1	SERIAL 03043031-09999999	3
7			GASKET, INLET SEAT	1		3,0
8			GASKET, FLOAT BOWL COVER	1		3,0
9	1399	1133	COVER, FLOAT BOWL	1	SERIAL 00000000-02979678	
9	1399	4559	COVER, FLOAT BOWL	1	SERIAL 03043031-09999999	
10	10	52195	SCREW, FLOAT BOWL COVER	1		
11	10	52196	SCREW, FLOAT BOWL COVER	1		
12	13	26995	LOCKWASHER, FLOAT BOWL C	2		
13			GASKET, STRAINER COVER (L	1		3,0
14	1399	3938	SCREEN, FILTER	1		
15			GASKET, STRAINER COVER (S	1		3,0
16	1399	2371	COVER, STRAINER	1		
17			GASKET, STRAINER COVER SC	1		3,0
18	10	25822	SCREW, STRAINER COVER FA	1		3
19	10	20847	SCREW, THROTTLE STOP LEV	1		3
20		33148	CLUSTER, THROTTLE STOP	1		
21	1399	3527	SHAFT, THROTTLE	1		
22			TUBE, IDLE	1		3
23	10	23178	SCREW, BODY (IDLE TUBE)	1	SERIAL 00000000-02979678	
23	1395	4540	SCREW, BODY (IDLE TUBE)	1	SERIAL 03043031-09999999	
24			GASKET, IDLE TUBE	1		3,0
25			SCREW AND LOCKWASHER, T	2		3
26	1399	3528	SHUTTER, THROTTLE	1		
27			SPRING, IDLE ADJUSTMENT S	1		3
28	1399	3515	SCREW, IDLE ADJUSTMENT	1		3
29	10	28405	SCREW, PLUG - MAIN FUEL JE	1	SERIAL 00000000-02979678	
29	1395	4541	SCREW, PLUG - MAIN FUEL JE	1	SERIAL 03043031-09999999	
30			GASKET, JET CHANNEL FLUG	1		3,0
31	1399	3519	JET, MAIN FUEL (.080)	OPT.		
31	1399	3520	JET, MAIN FUEL (.0785) - STANI	1		3
31	1399	3796	JET, MAIN FUEL (.076)	OPT.		
31	1399	3794	JET, MAIN FUEL (.074)	OPT.		
32			NOZZLE, MAIN	1		3
32	1399	2622	SCREW, PLUG - MAIN NOZZLE	1	SERIAL 00000000-02979678	