



4261

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	22339	NUT, FLYWHEEL	1,1,1		
2	12	26617	WASHER, FLYWHEEL NUT	1,1,1		
3	28	20094	KEY, FLYWHEEL DRIVE	1,1,1		
4	208	1385A 1	FLYWHEEL ASSEMBLY	1,,		
4	211	1414A 7	FLYWHEEL ASSEMBLY	,1,1		
5A	12	25293	WASHER, PULLY TO FLYWHEEL	1,1,,		
6A		22823	PULLEY, FLYWHEEL	1,1,,		
5		29788	FLANGE, FLYWHEEL PULLEY (1,1,1,1		
6		30306	PULLEY, FLYWHEEL	1,1,1,1		
7		29787	HUB, FLANGE - FLYWHEEL PULLEY	1,1,1,1		
8	17	26618	DOWEL PIN, FLYWHEEL PULLEY	1,1,1,1		
9	50	25263	RATCHET, FLYWHEEL	,1,1		
10	10	29238	SCREW, RATCHET TO FLYWHEEL	,3,3		
11	398	1455	STATOR, ALTERNATOR - FLYWHEEL	,1,1		
12		22647	DISCONNECT, KNIFE SPLICE	,2,2		
13	32	29267	SLEEVE, RUBBER - STATOR LEAD	,2,2		
14	10	29249	SCREW, STATOR TO UPPER END	,4,4		
15	54	24836	CLIP, STATOR LEAD TO CRANKCASE	,1,1		
16	10	30009	SCREW, STATOR LEAD CLIP FACE	,1,1		