



| Parts List | | | | | | |
|------------|-------|----------|-----------------------------|---------|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 177 | 1594A 2 | TOP COWL ASSEMBLY | 1,1,1,1 | | |
| 2 | 16 | 20500 | STUD, REAR - TOP COWL TO C | 2,2,2,2 | | |
| 3 | 16 | 20353 | STUD, FRONT - TOP COWL TO | 2,2,2,2 | | |
| 4 | 25 | 20116 | GROMMET, CHOKE KNOB | 1,1,1,1 | | |
| 5 | | 28967 | SCREEN, VENT - TOP COWL | 1,1,1,1 | | |
| 6 | 10 | 29221 | SCREW, VENT SCREEN TO TO | 4,4,4,4 | | |
| 7 | | 29228A 1 | TRIM MOULDING ASSEMBLY, 1 | 1,1,1,1 | | |
| 8 | 10 | 29226 | SCREW, DECORATIVE - MOU | 2,2,2,2 | | |
| 9 | 10 | 29227 | SCREW, BRASS - MOULDING | 2,2,2,2 | | |
| 10 | 13 | 26995 | LOCKWASHER, MOULDING F | 4,4,4,4 | | |
| 11 | 11 | 26419 | NUT, MOULDING FASTENING | 4,4,4,4 | | |
| 12 | 37 | 29834 | DECAL SET, TOP COWL | 1,1,, | | |
| 12 | 37 | 31008 | DECAL SET, TOP COWL | ,,1,1 | | |
| 13 | 23 | 20326 | SPACER, TOP COWL STUD | 2,2,2,2 | | |
| 14 | 12 | 20028 | WASHER, TOP COWL STUD (1/1 | 2,2,2,2 | | |
| 15 | 12 | 20346 | WASHER, TOP COWL STUD (3/4 | 4,4,4,4 | | |
| -- | 12 | 20583 | WASHER, TOP COWL STUD (1/3 | 4,4,4,4 | | |
| 16 | 11 | 20361 | NUT, TOP COWL FASTENING | 4,4,4,4 | | |
| 17 | | 20155 | RETAINER, STARTER SPRING | 1,1,1,1 | | |
| 18 | 24 | 23714 | SPRING, STARTER REWIND | 1,1,1,1 | | |
| 19 | 23 | 28912 | BUSHING, SPRING GUIDE | 1,1,1,1 | | |
| 20 | 50 | 28908 | SHEAVE ASSEMBLY | 1,1,,1 | | |
| 20 | 50 | 30994 | SHEAVE ASSEMBLY | ,,1, | | |
| 21 | | 20162 | PAWL, STARTER | 3,3,,3 | | |
| 21 | | 30596 | PAWL, STARTER | ,,3, | | |
| 22 | 13 | 29402 | WASHER, WAVE - STARTER PA | 3,3,,3 | | |
| 22 | 13 | 30597 | WASHER, WAVE - STARTER PA | ,,3, | | |
| 23 | 23 | 28919 | BUSHING, NYLON - SHEAVE SHA | 1,1,1,1 | | |
| 24 | 23 | 28911 | SPACER, SHEAVE SHAFT | 1,1,1,1 | | |
| 25 | | 26179 | RETAINER, WAVE WASHER | 1,1,1,1 | | |
| 26 | 12 | 26180 | WASHER, WAVE WASHER RETA | 1,1,1,1 | | |
| 27 | 13 | 20160 | WASHER, WAVE - RETAINER TE | 1,1,1,1 | | |
| 28 | | 20164 | PLATE, RETAINER - STARTER P | 1,1,,1 | | |
| 28 | | 30595 | PLATE, RETAINER - STARTER P | ,,1, | | |
| 29 | | 28913 | SHAFT, SHEAVE | 1,1,1,1 | | |
| 30 | 50 | 28985A 1 | STARTER CABLE ASSEMBLY | 1,1,1,1 | | |
| 31 | | 28747 | HANDLE, STARTER CABLE | 1,1,1,1 | | |
| 32 | | 28748 | RETAINER, STARTER CABLE AN | 1,1,1,1 | | |
| 33 | | 30045 | PLATE, ROPE GUIDE | 1,1,1,1 | | |
| 34 | 10 | 28642 | SCREW, DRIVE, ROPE GUIDE PL | 3,3,3,3 | | |
| 35 | 14 | 20165 | TAP WASHER, SHEAVE SHAFT A | 1,1,1,1 | | |