



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1626	3927A 4	GEAR HOUSING ASSEMBLY, CO	1	UNITED STATES 3344829 AND I	
-	1626	3927A 5	GEAR HOUSING ASSEMBLY, CO	1	UNITED STATES 3344829 AND I	
-	1643	4518A 7	GEAR HOUSING ASSEMBLY, CO	1	UNITED STATES 3344830 THRL	
-	1643	4518A 8	GEAR HOUSING ASSEMBLY, CO	1	UNITED STATES 3344830 THRL	
-	1643	4814A10	GEAR HOUSING ASSEMBLY, CO	1	UNITED STATES 3346835 THRL	
-	1643	4814A11	GEAR HOUSING ASSEMBLY, CO	1	UNITED STATES 3346835 THRL	
-	1643	4931A 9	GEAR HOUSING ASSEMBLY, CO	1	UNITED STATES 3474578 AND I	
-	1643	4931A10	GEAR HOUSING ASSEMBLY, CO	1	UNITED STATES 3474578 AND I	
1	1626	3927A 6	GEAR HOUSING ASSEMBLY	1	SEE PAGE 31 FOR BREAKDOWN	
1	1643	4518A 6	GEAR HOUSING ASSEMBLY	1	SEE PAGE 31 FOR BREAKDOWN	
1	1643	4814A 9	GEAR HOUSING ASSEMBLY	1	SEE PAGE 31 FOR BREAKDOWN	
1	1643	4931A 6	GEAR HOUSING ASSEMBLY	1	SEE PAGE 31 FOR BREAKDOWN	
51		36288	CAM, SHIFT	1	UNITED STATES 3859434 AND I	
51		54346	CAM, SHIFT	1	UNITED STATES 3859435 AND I	
52		38441	FOLLOWER, CAM	1		
53		20843	SLIDE, CROSS PIN	1		
54	24	39845	SPRING, COMPRESSION - CAM	1		
55	15	38374A 1	SHIM, BEARING CUP TO GEAR	AR		
56	31	38356A 1	TAPERED ROLLER BEARING A	1		
57	31	21739	BEARING, ROLLER - FORWARD	1		
58	43	55608	FORWARD GEAR ASSEMBLY	1		
59	52	47586	RATCHET, SLIDING CLUTCH	1		
60	17	38113	PIN, CROSS - RATCHET TO PR	1		
61	24	38114	SPRING, RETAINING - CROSS P	1		
62	44	55911	SHAFT, PROPELLER	1		
63	43	55609	REVERSE GEAR ASSEMBLY	1	UNITED STATES 3859434 AND I	
63	43	66554	REVERSE GEAR ASSEMBLY	1	UNITED STATES 3859435 AND I	
64	15	20927A 1	SHIM, THRUST WASHER TO G AR			
65	12	32004	WASHER, THRUST - REVERSE	1		
66	30	20839	BEARING, BALL - REVERSE GE	1		
67	25	31986	"O" RING, BEARING CARRIER	1		1,2,4
68		55904A 1	BEARING CARRIER ASSEMBLY	1		
69	31	21700	BEARING, ROLLER - BEARIN	1		
70	26	56788	OIL SEAL, BEARING CARRIE	1		
71	28	30281	KEY, LOCATING - BEARING CA	1		
72	14	53012	TAB WASHER, GEAR HOUSING	1		
73		53013	COVER, GEAR HOUSING	1		
74		31640A 1	TRIM TAB ASSEMBLY, GEAR H	1		
75	10	55726	SCREW, TRIM TAB TO GEAR H	1		
76	12	45175	WASHER, DRIVE SHAFT HOUSIN	1		
77	11	24962	NUT, DRIVE SHAFT HOUSING S	1		