



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	2138	4413A 2	TOP COWL ASSEMBLY	1		
2		58657	INSERT, ROPE GUIDE - TOP CO	1		
3	53	58656	RING, RETAINING - ROPE GUI	1		
4	16	21391	STUD, TOP COWL TO SUPPOR	1		
5	16	21553	STUD, TOP COWL TO SUPPOR	2		
6	11	35814	NUT, TOP COWL STUD	3		
7		62236	SHIELD, REAR - TOP COWL	1		
8	10	20646	SCREW, REAR SHIELD TO TOP	3		
9	12	26014	WASHER, REAR SHIELD SCREW	3		
10		39619	BUTTON, FRONT COVER RELEA	1		
11	24	37911	SPRING, COMPRESSION - FRON	1		
12		39493	CATCH, FRONT COVER - TOP CO	1		
13	10	25876	SCREW, FRONT COVER CATCH	2		
14	13	26996	LOCK WASHER, FRONT COVER I	2		
15		61867	BRACKET, SUPPORT - TOP COW	1	UNITED STATES 3859434 AND I	
15		67878	BRACKET, SUPPORT - TOP COW	1	UNITED STATES 3859435 AND I	
16		39501	MOUNT, RUBBER - REAR SUPPC	1		
17	11	20361	NUT, RUBBER MOUNT TO CYLIN	1		
18	11	20586	NUT, RUBBER MOUNT TO REAR	1		
19	10	37562	SCREW, REAR SUPPORT BRACK	4		
20	13	26993	LOCKWASHER, REAR SUPPORT	4		
21		62370	BRACKET, SUPPORT - TOP COW	1	UNITED STATES 3859434 AND I	
21		67323	BRACKET, SUPPORT - TOP COW	1	UNITED STATES 3859435 AND I	
22	10	37562	SCREW, FRONT SUPPORT BRAC	2		
23	13	26993	LOCKWASHER, FRONT SUPPOR	2		
24		39501	MOUNT, RUBBER - FRONT SUPP	2		
25	11	20361	NUT, RUBBER MOUNT TO CRAN	2		
26	11	20586	NUT, RUBBER MOUNT TO FRON	2		