



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1151	4732A 1	END CAP ASSEMBLY, UPPER	1	
2	25	47254	"O" RING, UPPER END CAP	1	4
3	31	62066	BALL BEARING, UPPER END C	1	
5	10	30225	SCREW, UPPER END CAP MOUN	4	
6	851	5350A 3	CYLINDER BLOCK AND CRANKC	1	UNITED STATES 4564001 AND I
6	851	6297A 3	CYLINDER BLOCK AND CRANKC	1	UNITED STATES 4564002 AND I
7	16	68164	STUD, CARBURETOR MOUNTIN	2	
8	16	68165	STUD, CRANKCASE TO DRIVE	2	
9	16	68168	STUD, CYLINDER BLOCK TO D	2	
10	16	68166	STUD, CYLINDER BLOCK TO D	2	
11	16	68167	STUD, CYLINDER BLOCK TO DR	2	
12	17	57211	DOWEL PIN, RETAINER TO C	1	
13	17	23784	DOWEL PIN, CRANKCASE TO C	2	
14	17	20323	DOWEL PIN, CYLINDER BLOCK	1	
15	27	55158	GASKET, SEALING-CYLINDER B	2	4
16		62064	BRACKET, STARTER MOTOR	1	
17	10	35213	SCREW, BLOCK BRACKET TO ST.	2	
17	10	21339	SCREW, STARTER MOTOR BRAC	2	
18	11	46793	NUT, STARTER MOTOR BRACKE	2	
19	10	69096	SCREW, CRANKCASE TO CYLIN	6	UNITED STATES 4564001 AND I
19	10	69098	SCREW, CRANKCASE TO CYLIN	2	UNITED STATES 4564001 AND I
19	10	69090	SCREW, CRANKCASE TO CYLIN	1	UNITED STATES 4564001 AND I
20	11	46793	NUT, CRANKCSAE FASTENING SI	9	UNITED STATES 4564001 AND I
19	10	73657	SCREW, CRANKCASE TO CYLIN	7	UNITED STATES 4564002 AND I
19	10	63328	SCREW, CRANKCASE TO CYLIN	2	UNITED STATES 4564002 AND I
21	1152	4966A 1	END CAP ASSEMBLY, LOWER	1	
22	26	29476	OIL SEAL, LOWER END CAP	2	
23	25	64068	"O" RING, LOWER END CAP SCR	3	4
24	25	64067	"O" RING, LOWER END CAP	1	4
25	10	63365	SCREW, LOWER END CAP TO CY	3	
26	27	55306	GASKET, CYLINDER BLOCK TO B.	1	4
27		55190	PLATE, DIVIDER-EXHAUST MANI	1	
28	27	55308	GASKET, BAFFLE PLATE TO EXH.	1	4
29		55157	COVER, EXHAUST MANIFOLD	1	
30	10	69092	SCREW, MANIFOLD COVER TO C	1	
30	10	69099	SCREW, MANIFOLD COVER TO C	7	
31	10	64021	SCREW, ADJUSTING-EXHAUST C	2	
32	11	64015	NUT, ADJUSTING SCREW	2	
33		26852	CAP, NYLON-ADJUSTING SCREW	2	
34	1024	3869	COVER, CYLINDER BLOCK	1	UNITED STATES 4362214 AND I
35	27	55207	GASKET, CYLINDER BLOCK COV	1	UNITED STATES 4362214 AND I