



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1352	4853A 1	CARBURETOR ASSEMBLY, COM	1	
2	1399	110A 1	FLOAT ASSEMBLY	1	
3			PIN, FLOAT LEVER PINION	2	3
4			LEVEL, FLOAT (LOWER)	1	3
5			LEVER, FLOAT (UPPER)	1	3
6	1395	4555	INLET NEEDLE, SEAT AND GA	1	3
7			GASKET, INLET SEAT	1	3,0
8			GASKET, FLOAT BOWL COVER	1	3,0
9	1399	4559	COVER, FLOAT BOWL	1	
10	10	52195	SCREW, FLOAD BOWL COVER	1	
11	10	52196	SCREW, FLOAD, FOWL COVER	1	
12	13	26995	LOCKWASHER, FLOAD BOWL C	2	
13			GASKET, STRAINER COVER (L	1	3,0
14	1399	3938	SCREEN, FILTER	1	3
15			GASKET, STRAINER COVER (S	1	3,0
16	1399	2371	COVER, STRAINER	1	
17			GASKET, STRAINER COVER SC	1	3,0
18	10	25822	SCREW, STRAINER COVER FA	1	3
19	10	20847	SCREW, THROTTLE STOP LEV	1	3
20		56498	CLUSTER, THROTTLE STOP	1	
21	1399	3527	SHAFT, THROTTLE	1	
22			TUBE, IDLE	1	3
23	1395	4540	SCREW, BODY (IDLE TUBE)	1	
24			SCREW AND LOCKWASHER, T	2	3
25	1399	3528	SHUTTER, THROTTLE	1	
26			SPRING, IDLE ADJUSTMENT S	1	3
27	1399	3515	SCREW, IDLE ADJUSTMENT	1	3
28	1395	4541	SCREW, PLUG - MAIN FUEL JE	1	
29			GASKET, JET CHANNEL PLUG	1	3,0
30	1399	3519	JET, MAIN FUEL (.080)	OPT	
30	1399	3520	JET, MAIN FUEL (.0785) - STANI	1	3
30	1399	3796	JET, MAIN FUEL (.076)	OPT	
30	1399	3794	JET, MAIN FUEL (.074)	OPT	
31			NOZZLE, MAIN	1	3
32	1395	4542	SCREW, PLUG - MAIN NOZZLE	1	
33			SPRING, THROTTLE SHAFT RET	1	3
34			WELCH PLUG, BODY CHANNEL	1	3
35	1395	4543	SCREW, BODY CHANNEL	1	
--	1399	3523	GASKET AND PACKING SET (1 PI	1	
--	1399	4556	REPAIR PARTS KIT (1 PER CARB	1	
36	27	48164	GASKET, CARBURETOR FLANGE	1	21.202.4