



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	2138	4413A 2	TOP COWL ASSEMBLY	1		
2		58657	INSERT, ROPE GUIDE - TOP COWL	1		
3	53	58656	RING, RETAINING - ROPE GUIDE	1		
4	16	21391	STUD, TOP COWL TO SUPPORT	1		
5	16	21553	STUD, TOP COWL TO SUPPORT	2		
6	11	35814	NUT, TOP COWL STUD	3		
7		62236	SHIELD, REAR - TOP COWL	1		
8	10	20646	SCREW, REAR SHIELD TO TOP COWL	3		
9	12	26014	WASHER, REAR SHIELD SCREW	3		
10		39619	BUTTON, FRONT COVER RELEASE	1		
11	24	37911	SPRING, COMPRESSION - FRONT COVER	1		
12		39493	CATCH, FRONT COVER - TOP COWL	1		
13	10	25876	SCREW, FRONT COVER CATCH	2		
14	13	26996	LOCK WASHER, FRONT COVER CATCH	2		
15		61867	BRACKET, SUPPORT - TOP COWL	1	UNITED STATES 3859434 AND I	
15		67878	BRACKET, SUPPORT - TOP COWL	1	UNITED STATES 3859435 AND I	
16		39501	MOUNT, RUBBER - REAR SUPPORT	1		
17	11	20361	NUT, RUBBER MOUNT TO CYLINDER	1		
18	11	20586	NUT, RUBBER MOUNT TO REAR	1		
19	10	37562	SCREW, REAR SUPPORT BRACKET	4		
20	13	26993	LOCKWASHER, REAR SUPPORT BRACKET	4		
21		62370	BRACKET, SUPPORT - TOP COWL	1	UNITED STATES 3859434 AND I	
21		67323	BRACKET, SUPPORT - TOP COWL	1	UNITED STATES 3859435 AND I	
22	10	37562	SCREW, FRONT SUPPORT BRACKET	2		
23	13	26993	LOCKWASHER, FRONT SUPPORT BRACKET	2		
24		39501	MOUNT, RUBBER - FRONT SUPPORT	2		
25	11	20361	NUT, RUBBER MOUNT TO CRANK	2		
26	11	20586	NUT, RUBBER MOUNT TO FRONT	2		