



| Parts List | | | | | | |
|------------|-------|----------|-----------------------------|-----|----------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| | 1643 | 6459A10 | GEAR HOUSING ASSY, COMP. | 1 | (SHORT SHAFT); SERIAL GROU | 1 |
| | 1643 | 6459A11 | GEAR HOUSING ASSY, COMP. | 1 | (LONG SHAFT); SERIAL GROUP | 1 |
| | 1643 | 7406A14 | GEAR HOUSING ASSY, COMP. | 1 | (SHORT SHAFT); SERIAL GROU | 1 |
| | 1643 | 7406A15 | GEAR HOUSING ASSY, COMP. | 1 | (LONG SHAFT); SERIAL GROUP | 1 |
| 1 | 1643 | 6459A 3 | GEAR HOUSING ASSY | 1 | SEE GEAR HOUSING ASSEMBL' | |
| 1 | 1643 | 7406A16 | GEAR HOUSING ASSY | 1 | SEE GEAR HOUSING ASSEMBL' | |
| 51 | | 54346 | CAM, SHIFT | 1 | | |
| 51 | | 76039 | CAM, SHIFT | 1 | SERIAL GROUP #2 | |
| 52 | | 38441 | FOLLOWER, CA | 1 | | |
| 53 | | 20843 | SLIDE, CROSS PIN | 1 | | |
| 54 | 24 | 39845 | SPRING, COMPRESSION - CAM | 1 | | |
| 55 | 15 | 38374A 1 | SHIM, BEARING CUP TO GEAR | AR | (.002-3-5-10) | 7 |
| 56 | 31 | 38356A 1 | TAPERED ROLLER BEARING A | 1 | | |
| 57 | 13 | 21739 | BEARING, ROLLER - FORWARD | 1 | | |
| 58 | 43 | 55608 | FORWARD GEAR ASSEMBLY | 1 | | |
| 59 | 52 | 47586 | RATCHET, SLIDING CLUTCH | 1 | | |
| 60 | 17 | 38113 | PIN, CROSS - RATCHET TO PR | 1 | | |
| 61 | 24 | 38114 | SPRING, RETAINING - CROSS F | 1 | | |
| 62 | 44 | 75365 | SHAFT, PROPELLER | 1 | | |
| 63 | 43 | 79158A 1 | REVERSE GEAR ASSEMBLY | 1 | | |
| 65 | 12 | 32004 | WASHER, THRUST - REVERSE | 1 | | |
| 66 | 30 | 20839 | BEARING, BALL - REVERSE GE | 1 | | |
| 67 | 25 | 31986 | "O" RING, BEARING CARRIER | 1 | | 4 |
| 68 | | 69386A 1 | BEARING CARRIER ASSEMBLY | 1 | | |
| 69 | 31 | 21700 | BEARING, ROLLER - BEARIN | 1 | | |
| 70 | 26 | 69188 | OIL SEAL, BEARING CARRIEF | 1 | | |
| 71 | 26 | 69189 | OIL SEAL, BEARING CARRIEF | 1 | | |
| 72 | 28 | 30281 | KEY, LOCATING - BEARING CA | 1 | | |
| 73 | 14 | 53012 | TAB WASHER, GEAR HOUSING | 1 | | |
| 74 | | 53013 | COVER, GEAR HOUSING | 1 | | |
| 75 | | 31640A 1 | TRIM TAB ASSEMBLY, GEAR H | 1 | | |
| 76 | 10 | 66024 | SCREW, TRIM TAB TO GEAR H | 1 | | |
| 77 | 12 | 45175 | WASHER, DRIVE SHAFT HOUSIN | 1 | | |
| 78 | 11 | 34863 | NUT, DRIVE SHAFT HOUSING S | 1 | | |
| 79 | 12 | 65791 | WASHER | 1 | DRIVE SHAFT HOUSING TO GE, | |
| 80 | 11 | 34933 | NUT | 1 | DRIVE SHAFT HOUSING TO GE, | |
| 81 | | 73345 | THRUST HUB, FRONT | 1 | | |
| 84 | 14 | 76281 | TAB WASHER, PROPELLER | 1 | | |
| 85 | 11 | 69578 | NUT, PROPELLER | 1 | | |