



| Parts List |       |          |                             |     |                           |          |
|------------|-------|----------|-----------------------------|-----|---------------------------|----------|
| Ref        | Class | Part     | Description                 | Qty | Comment                   | Footnote |
| 1          | 2139  | 6424A 1  | BOTTOM COWL                 | 1   |                           |          |
| 2          |       | 48472    | COVER, PLUG - BOTTOM COWL   | 1   | MANUAL                    |          |
| 3          | 10    | 61802    | SCREW, PLUG COVER TO BOT    | 2   | MANUAL                    |          |
| 4          | 27    | 62860    | GASKET                      | 1   | POWERHEAD TO EXHAUST EX   | 9        |
| 5          |       | 39622    | SEAL, RUBBER                | 1   | EXHAUST PLATE TO BOTTOM C |          |
| 6          |       | 72014A 2 | PLATE ASSEMBLY, EXHAUST EX  | 1   | SERIAL GROUP #1           |          |
| 7          |       | 79614A 1 | PLATE ASSEMBLY, EXHAUST EX  | 1   | SERIAL GROUP #1           |          |
| 7          | 23    | 71980    | BUSHING, FLANGE EXHAUST F   | 1   |                           |          |
| 8          | 12    | 38453    | WASHER, NYLON - WATER OUT   | 1   |                           |          |
| 9          | 26    | 38452    | SEAL, RUBBER - WATER OUTL   | 1   |                           | 9        |
| 10         |       | 38500    | RETAINER, WATER OUTLET T    | 1   | SERIAL GROUP #1           |          |
| 11         | 10    | 74035    | SCREW RETAINER TO EXHAU     | 1   | SERIAL GROUP#1            |          |
| 12         |       | 79799    | HOUSING, WATER INLET TUBE   | 1   | SERIAL GROUP #2           |          |
| 13         | 27    | 79797    | GASKET, HOUSING             | 1   | SERIAL GROUP #2           | 9        |
| 14         | 10    | 79798    | SCREW, HOUSING TO EXHAU     | 2   | SERIAL GROUP #2           |          |
| 15         | 27    | 38501    | GASKET                      | 1   | EXHAUST PLATE TO DRIVE SH | 9        |
| 16         |       | 37637    | BOOT, FUEL CONNECTOR - BOT  | 1   |                           |          |
| 17         |       | 39616    | BOOT, CONTROL CABLE - BOT   | 1   |                           |          |
| 18         |       | 39555A 1 | COVER PLATE ASSEMBLY        | 1   |                           |          |
| 19         |       | 39556    | PAD, SOUND - COVER PLATE    | 1   |                           |          |
| 20         | 10    | 69014    | SCREW, COVER PLATE TO BOT   | 3   |                           |          |
| 21         | 87    | 69508A 5 | STOP SWITCH ASSEMBLY        | 1   | MANUAL                    |          |
| 22         | 11    | 69844    | NUT, STOP SWITCH            | 1   | MANUAL                    |          |
| 23         |       | 76176    | LEVER, FRONT COVER          | 1   |                           |          |
| 24         | 17    | 26541    | ROLL PIN, LEVER TO BOTTOM C | 1   |                           |          |
| 25         | 24    | 76177    | SPRING, FRONT COVER LEVER   | 1   |                           |          |