



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	2138	6341	TOP COWL ASSEMBLY (ELECTRI	1		
1	2138	6340A	TOP COWL ASSEMBLY (MANUAL	1		
2		73537	INSERT, ROPE GUIDE	1	SERIAL GROUP #1	
3	53	58656	RING, RETAINING - INSERT	1	SERIAL GROUP #1	
2		77859	GUIDE, STARTER ROPE	1	SERIAL GROUP #2	
3		77860	RING, RETAINING - GUIDE	1	SERAIL GROUP #2	
4		62236	SHIELD, REAR - TOP COWL	1		
5	10	20646	SCREW, REAR SHIELD TO TOP CC	3		
6	12	26014	WASHER, REAR SHIELD SCREW	3		
7		76132	BRACKET, SUPPORT - TOP COW	1		
8		60577	MOUNT, RUBBER - REAR SUPPC	2		
9	12	26014	WASHER, RUBBER MOUNT	2		
10	12	21631	WASHER, RUBBER MOUNT	AR		7
11	13	26992	LOCKWASHER, RUBBER MOUN	2		
12	11	36069	NUT, RUBBER MOUNT	2		
13		39501	MOUNT, RUBBER - REAR SUPPC	1		
14	11	36069	NUT, RUBBER MOUNT TO CYLIN	1	LOWER	
15	11	36069	NUT, RUBBER MOUNT TO REAR	1	UPPER	
16	10	37562	SCREW, REAR SUPPORT BRACK	4	(1")	
17	13	26993	LOCKWASHER, REAR SUPPORT	4		
18		76133	BRACKET, SUPPORT - TOP COW	1		
19		31014	MOUNT, RUBBER - FRONT SUPP	2		
20	12	26014	WASHER, RUBBER MOUNT	2		
21	12	21631	WASHER, RUBBER MOUN	AR		7
22	13	26992	LOCKWASHER, RUBBER MOUN	2		
23	11	36069	NUT, RUBBER MOUNT	2		
24	10	37562	SCREW	2	FRONT SUPPORT BRACKET TO	
25	13	26993	LOCKWASHER, FRONT SUPPOR	2		
26		39501	MOUNT, RUBBER - FRONT SUPP	2		
27	11	36069	NUT, RUBBER MOUNT TO CRAN	2		
28	11	36069	NUT, RUBBER MOUNT TO FRON	2	UPPER	
29		55455	HOOK, TOP COWL LATCH - REAF	1		
30	10	22956	SCREW, REAR HOOK TO TOP CC	2		
31	13	26992	LOCKWASHER, REAR HOOK SCF	2		
32		75973	PLATE, HINGE	1		
33	10	32228	SCREW, HINGE PLATE (5/8")	2		
34	13	26996	LOCKWASHER, HINGE PLATE SC	2		
35		52737	LEVER, COWL LATCH	1		
36		52739	HINGE, COWL LATCH LEVER	1		
37	17	58998	ROLL PIN, HINGE TO LEVER	1		