



7466

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		72040	BRACKET, Throttle Actuator	1		
2	10	53576	SCREW, Throttle Actuator Bracket	3	(1.125 Inch)	
3	13	26993	LOCKWASHER, (.312), Throttle Ac	3		
4		72032	ACTUATOR, Throttle	1		
5	10	21449	SCREW, (.312-24 x 2.00), Bracket	1		
6	12	25893	WASHER, Bracket Screw	2		
7	13	62172	WAVE WASHER, Bracket Screw	1		
8	11	29250	NUT, Bracket Screw	1		
9		57440	SWIVEL, Link Rod to Throttle Actu	1		
10		72043	LINK ROD	1		
11		57440	SWIVEL, Link Rod to Throttle Arm	1		
12		76560	ARM, Throttle	1		
13	10	55903	SCREW, Adjusting - Throttle Arm	1	(2.25 Inch)	
13	10	25158	SCREW, (.190-32 x 1.75), Adjusting	1		
14	11	68219	NUT, (#10-32), Adjusting Screw	2		
15		48039	CAP, Adjusting Screw	2		
16		39483	LATCH, Throttle Arm	1		
17	10	22486	SCREW, (.250-28 x .88), Latch to T	1		
18	24	20099	SPRING, Compression - Latch Scre	1		
19	11	20586	NUT, Latch Screw	1		
20		76559A	LEVER, Spark Advance	1		
21	10	55337	SCREW, Lever and Arm to Cylinder	1	(1.75 Inch)	
22	23	55164	BUSHING, Lever and Arm Screw	1		
23	23	55171	BUSHING, Lever and Arm Screw	1		
24	24	55162	SPRING, Return - Spark Advance	1		
25	12	68410	WASHER, Lever and Arm Screw	1		
26	10	25158	SCREW, (.190-32 x 1.75), Adjusting	1		
27	11	68219	NUT, (#10-32), Adjusting Screw	1		
28		48039	CAP, Adjusting Screw	1		
29		76056	LINK ROD, Spark Advance	1	(2.50 Inch Long)	
30		74897	PIVOT, Threaded - Link Rod to Tric	1		
31		77013A	SWIVEL, Link Rod to Spark Advan	1		
32	13	29402	WAVE WASHER, Swivel	1		
33	23	26856	BUSHING, Link Rod Swivel	1		
34	12	33786	WASHER, Link Rod Swivel	1		
35	11	45774	NUT, Link Rod Swivel	1		
36		66778	PLATE, Throttle Actuator	1		
37	10	46420	SCREW, Plate to Throttle Actuator	2	(.50 Inch Length)	
38	10	23015	SCREW, (.190-32 x 1.00), Adjusting	1		
39	11	68219	NUT, (#10-32), Adjusting Screw	1		
40		48039	CAP, Adjusting Screw	1		