



7482

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1643	9539A 4	GEAR HOUSING, Short Shaft - Bla	1		
-	1643	9539A 5	GEAR HOUSING, Long Shaft - Bla	1		
-	1643	9539A 6	GEAR HUSING ASSEMBLY, Short	1		
-	1643	9539A 7	GEAR HOUSING ASSEMBLY, Lon	1		
1	1643	9539A 1	GEAR HOUSING	1	Black	
1	1643	9539A 8	GEAR HOUSING ASSEMBLY	1	Gray	
51		76039	SHIFT CAM	1		
52	15	38374A 1	SHIM, Bearing Cup to Gear Hous	AR		
53	31	38356A 1	BEARING SET	1		
54	43	55608A 4	FORWARD GEAR	1		
55	31	21739	ROLLER BEARING, Foward Ge	1		
56		38441	CAM FOLLOWER	1		
57		20843	SLIDE, Cross Pin	1		
58	24	38114	SPRING, Retaining - Cross Pin	1		
59	52	92911	RATCHET, Sliding Clutch	1		
60	17	38113	CROSS PIN, Ratchet to Propeller	1		
61	24	39845	SPRING, Compression - Cam Foll	1		
62	44	75365	PROPELLER SHAFT	1		
63	43	79158	REVERSE GEAR	1		
64	12	32004	WASHER, Thrust - Reverse Gear	1		
65	30	20839	BALL BEARING, Reverse Gear	1		
66	25	31986	O RING, Bearing Carrier	1		17,19
67		69386A 1	BEARING CARRIER ASSEMBLY	1		
68	31	21700	ROLLER BEARING, Bearing Cc	1		
69	26	69188	OIL SEAL, Bearing Carrier	1		19
70	26	69189	OIL SEAL, Bearing Carrier	1		19
71	28	30281	KEY, Locating - Bearing Carrier	1		
72	14	53012	TAB WASHER, Gear Housing Cc	1		
73	11	87763	NUT, Gear Housing	1		
74		31640A 1	TRIM TAB ASSEMBLY, Gear Ho	1		
75	10	66024	SCREW, (7/16-14 x 1-3/4), Trim	1		
76	12	45175	WASHER, Driveshaft Housing Stuc	1		
77	11	34863	NUT, (.375-24), Driveshaft Housing	1		
78	12	65791	WASHER, Housing to Stud (0.437	1		
79	11	34933	NUT, (.437-20), Stud	1		
80		73345A 1	THRUST HUB, Front	1		
81	14	<a href="#">76281</a>	TAB WASHER, Propeller Nut	1		
82	11	69578A 1	PROPELLER NUT	1		
-	26	79831A1	SEAL REPAIR KIT	1		
-	27	85491A87	GASKET SET	-		