



| Parts List | | | | | | |
|------------|-------|--------|------------------------------|-----|----------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 76395A | 5 PUMP ASSY (METAL RES | 1 | SEE HYDRAULIC PUMP ASSEMI | |
| 1 | | 92975A | 6 PUMP ASSY (PLASTIC RE | 1 | SEE HYDRAULIC PUMP ASSEMI | |
| 1 | 25 | 48171 | "O" RING, MANIFOLD PLATE (SI | 4 | | |
| 2 | 10 | 79953 | SCREW, FILLER - HYDRUALIC | 1 | | |
| 3 | 12 | 20260 | WASHER, SEALIN - FILLER SCF | 1 | | |
| 4 | 10 | 62269 | SCREW, VENT - HYDRAULIC PI | 1 | | |
| 5 | | 32979 | BATTERY LEAD (POSITIVE) | 1 | | |
| 6 | | 32988 | BATTERY LEAD (NEGATIVE) | 1 | | |
| 7 | | 45336 | PLATE, MANIFOLD | 1 | | |
| 8 | | 45197A | 2 CONTROL VALVE ASSEMBLY | 1 | | |
| -- | 25 | 48171 | "O" RING, MANIFOLD PLATE (SI | 4 | | |
| 9 | 25 | 45254 | "O" RING, CONTROL VALVE (3, | 1 | | |
| 10 | 25 | 48171 | "O" RING, CONTROL VALVE (1, | 1 | | |
| 11 | 25 | 45253 | "O" RING, CONTROL VALVE (5, | 2 | | |
| 12 | 10 | 56500 | SCREW | 4 | VALVE AND MANIFOLD PLATE 1 | |
| 13 | 22 | 46008 | PLUG, CONTROL VALVE (1/2-20" | 2 | | |
| 14 | 84 | 74023A | 1 CONNECTOR AND HARNESS | 1 | | |
| 15 | | 45377 | BRACKET, MOUNTING | 2 | | |
| 16 | 10 | 35386 | SCREW | 4 | MOUNTING BRACKET TO HYDF | |
| 17 | 13 | 39107 | LOCKWASHER, MOUNTING BRA | 4 | | |
| 18 | 11 | 21908 | NUT, MOUNTING BRACKET SCR | 4 | | |
| 19 | 10 | 68298 | BOLT, HYDRUALIC PUMP TO BO, | 2 | | |
| 20 | 11 | 99405 | NUT, HYDRAULIC PUMP BOLT | 2 | | |
| 21 | 89 | 68258 | STARTER SOLENOID | 2 | | |
| 22 | 13 | 26996 | LOCKWASHER, SOLENOID TERN | 4 | | |
| 23 | 11 | 68219 | NUT, SOLENOID TERMINAL (#10 | 4 | | |
| 24 | 13 | 26993 | LOCKWASHER, SOLENOID TERN | 4 | | |
| 25 | 11 | 68292 | NUT, SOLENOID TERMINAL (5/1) | 4 | | |
| 26 | | 46265 | BOOT, RUBBER - STARTER SOLI | 4 | | |
| 27 | | 74407 | BRACKET, MOUNTING - STARTE | 1 | | |
| 28 | 10 | 21140 | SCREW | 2 | MOUNTING BRACKET TO HYDF | |
| 29 | 13 | 26992 | LICKWASHER, MOUNTING BRAC | 2 | | |
| 30 | 11 | 24656 | NUT | 1 | MOUNING BRACKET TO HYDRA | |
| 31 | | 26901 | BUMPER, RUBBER - SOLENOID E | 1 | | |
| 32 | 84 | 79139A | 2 JUMPER WIRE (POSITIVE) | 1 | | |
| 32 | | 55992 | JUMPER WIRE (NEGATIVE) | 1 | | |
| 33 | | 74406 | BRACKET, MOUNTING - STARTE | 1 | | |
| 34 | 10 | 69028 | SCREW | 2 | MOUNTING BRACKET TO HYDF | |
| 35 | 13 | 26992 | LOCKWASHER, MOUNTING BRA | 2 | | |
| 36 | 10 | 32417 | SCREW | 2 | STARTER SOLENOID TO MOUN | |
| 37 | 12 | 26992 | LOCKWASHER, STARTER SOLE | 2 | | |