



7464

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	20166	NUT, Sheave Shaft (Left Hand Thr	1		11
2	14	61004	TAB WASHER, Sheave Shaft Nut	1		11
3		89016 2	STARTER HOUSING	1		11
4	50	44255A 1	STARTER SHEAVE	1		11
5		44508	STARTER PAWL	1		11
6	10	54523	SCREW, Starter Housing	3		
7	13	20202	LOCKWASHER, Starter Housing S	3		
8		37691	PLATE, Cable Guide	1		11
9	10	35881	SCREW, (#6-32 x .250), Drive - Cal	3		11
10		61002	PLATE, Starter Rewind	1		
11	24	39502A 1	SPRING	1		11
12	23	87649	BUSHING, Spring Guide	1		11
13	24	87651	SPRING, Starter Pawl	1		11
14	53	87706	E RING, Starter Pawl	1		11
15	23	63061	SPACER, Sheave Shaft	1		11
17		94962	LEVER	1		11
18	13	20160	WAVE WASHER	1		11
19		87656	SHEAVE SHAFT	1		11
20	50	12066A 9	STARTER ROPE	1		11
20		47341A 1	EMERGENCY STARTER ROPE, F	1		
21		85174A 1	HANDLE ASSEMBLY	1		
22		76568	CABLE, Interlock	1	(Also Used on Electric Tiller Handl	
23	10	69022	SCREW, (#10-32 x .500), Interlock	2	(Also Used on Electric Tiller Handl	
24	12	33786	WASHER, Interlock Cable Screw	2	(Also Used on Electric Tiller Handl	
25		42820	CAM, Interlock	1		11
26	10	76138	SCREW, Interlock Cam (1.125 Inct	1		11
27	24	76140	SPRING, Interlock Cam Screw	1		11
28		79371	ACTUATOR, Interlock	1		11
29	10	76137	SCREW, Interlock Actuator (1.625	1		11
30	24	76139	SPRING, Interlock Actuator Screw	1		11
31	18	27769	COTTER PIN, Interlock Cable to Ac	1		
32	12	35559	WASHER, Starter Rewind	1		11
-		89016A3	STARTER REWIND ASSEMBLY	1		