



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		822649T	EXHAUST VALVE	4		6
2		822648	INTAKE VALVE	4		6
3	12	825044	SEAT-VALVE SPRING	8		6
4	26	822647	SEAL-VALVE STEM	8		2,6
5	24	823678	VALVE SPRING-OUTER	8		6
6		822650	RETAINER-VALVE SPRING	8		6
7		822651	KEY	16		6
8		825045A 1	ROCKER ARM	8		6
9	10	825046	SCREW	8		6
10	11	826150	NUT	8		6
11		825049	ROCKER SHAFT	1		6
12		825050	PLATE	2		6
13		825051	PLATE	1		6
14	24	825052	SPRING	2		6
15	10	826410 30	SCREW (M8 X 30)160	5		6
16	19	825042	PLUG	2		6
-	27	832013A,96	GASKET SET	1		
-		825034A12	CYLINDER HEAD ASSY.	1		