



| Parts List | | | | | | |
|------------|-------|----------|------------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| - | 1667 | 9011A69 | GEAR HOUSING (LONG) (BLACK) | 1 | | |
| - | 1667 | 9011A71 | GEAR HOUSING (X-LONG) (BLAC) | 1 | | |
| - | 1667 | 9011A70 | GEAR HOUSING (LONG) (GRAY) | 1 | | |
| - | 1667 | 9011A72 | GEAR HOUSING (X-LONG) (GRAY) | 1 | | |
| 1 | 1667 | 9011A73 | GEAR HOUSING ASSEMBLY (BI | 1 | | |
| 1 | 1667 | 9011A74 | GEAR HOUSING ASSEMBLY (G | 1 | | |
| 42 | 31 | 30894A 1 | TAPERED ROLLER BEARING A | 1 | | |
| 43 | 43 | 12634A 2 | FORWARD GEAR | 1 | | |
| 44 | 31 | 30895 | ROLLER BEARING | 1 | | |
| 45 | | 12239A 1 | CAM FOLLOWER ASSEMBLY | 1 | | |
| 45A | 30 | 44530 | BALL | 3 | | |
| 46 | 24 | 30622 | SPRING | 1 | | |
| 47 | 52 | 822539 | CLUTCH | 1 | | |
| 48 | 17 | 30632 | CROSS PIN | 1 | | |
| 49 | 24 | 30893 | SPRING | 1 | | |
| 50 | 44 | 12238T | PROPELLER SHAFT | 1 | | |
| 51 | 43 | 12635 | REVERSE GEAR | 1 | | |
| 52 | | 12596A 2 | BEARING CARRIER ASSEMBLY | 1 | | |
| 53 | 25 | 97386 | O-RING | 1 | | 15 |
| 54 | 31 | 30956 | ROLLER BEARING | 1 | | |
| 55 | 26 | 76868 | OIL SEAL (INNER) | 1 | | 15 |
| 56 | 26 | 70081 | OIL SEAL (OUTER) | 1 | | 15 |
| 57 | 31 | 12578 | ROLLER BEARING | 1 | | |
| 58 | 12 | 12577 | THRUST WASHER | 1 | | |
| 59 | 31 | 12576 | THRUST BEARING | 1 | | |
| 60 | 10 | 40003 54 | SCREW | 2 | | |
| 61 | 12 | 40023 17 | WASHER | 2 | | |
| 62 | 15 | 44491A 1 | SHIM ASSEMBLY | 1 | | |
| 63 | | 13191A 1 | THRUST HUB ASSEMBLY | 1 | | |
| 64 | 14 | 816629 | TAB WASHER | 1 | | |
| 65 | 11 | 52707A 1 | PROPELLER NUT ASSEMBLY | 1 | | |
| - | 26 | 43035A 4 | G/H SEAL KIT | 1 | | |