



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		14360A41	FUEL PUMP ASSEMBLY	1		
2	21	42990A10	DIAPHRAGM KIT	1		2
3		NSS	RUBBER CHECK VALVE	2		7
4		NSS	CHECK VALVE	2		7
5		NSS	RETAINER	2		7
6		NSS	SPRING	1		7
7		NSS	SPRING	1		7
8		NSS	SPRING	1		7
9		NSS	CAP	1		7
10		NSS	DIAPHRAGM	1		7
11	27	98769 1	GASKET	1		2
12		98775A 7	PLATE	1		
13	22	56800	PIPE PLUG	1		
14	22	19688A 1	FITTING	1		
15	10	40093 40	SCREW (40MM)	2		
16	10	40057134	SCREW (50MM)	2		
17		14430 3	BASE	1		
18	32	816865	HOSE	1		
19	35	816296 1	FUEL FILTER	1		
20	32	19723	FUEL LINE	1		
21	32	99129 80	HOSE	2		
22		13773	TEE	1		
23	54	816311	STA-STRAP	AR		
24	22	816856A 1	FUEL CONNECTOR	1		
25	10	40003 32	SCREW	1		
26	32	99127109	HOSE (4-3/4")	1		
27	22	19688	FITTING (90_)	1		
28	54	42859 3	SOLENOID VALVE	1		
29	54	63300 1	CLAMP	1		
30	10	40011127	SCREW	1		
31	32	14301 65	HOSE	3		
32	22	59169	TEE FITTING	1		
-	32	99130122	HOSE	1		
-	27	812867A97	ENGINE GASKET SET	1		
-	21	857005A 1	DIAPHRAGM KIT	1		