



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	4000	813010A 8	TOP COWL	1	ELECTRIC (BLACK)	1
1	4000	813010A14	TOP COWL	1	ELECTRIC (SILVER)	1
1	4005	816534A 8	TOP COWL	1	MANUAL (BLACK)	1
1	4005	816534A14	TOP COWL	1	MANUAL (SILVER)	1
2		824666	AIR INLET SHIELD	1		
3	10	40067 31	SCREW (M6 X 16)	4		
4		47341A11	STARTER ROPE	1	MANUAL STARTING	6
5		NSS	ENVELOPE	1	MANUAL STARTING	7
6		813548A 3	COWL SUPPORT BRACKET	1	BLACK	
6		813548A 6	COWL SUPPORT BRACKET	1	SILVER	
7		823187 1	SCREW (M4 X 14.5)	2		
8	13	26995	LOCKWASHER	2		
9	11	823751 5	NUT	2		
10		813549A 2	COWL SUPPORT BRACKET	1	REAR	
11	10	823187 1	SCREW (M4 X 14.5)	3		
12	13	26995	LOCKWASHER	3		
13	11	823751 5	NUT	3		
14		814336A 1	SOUND BLANKET-FRONT	1	ELECTRIC	
15		NSS	SOUND BLANKET-FRONT	1	MANUAL	7
16		NSS	SOUND BLANKET-SIDE	1	STARBOARD	7
17		NSS	SOUND BLANKET-SIDE	1	PORT	7
18		NSS	SOUND BLANKET-REAR	1		7
19		44462 2	SEAL	1		
20		813504A 1	OIL LEVEL GAUGE	1	ELECTRIC	
21		813505	GROMMET	1	ELECTRIC	
22		11317 1	RETAINER	1	ELECTRIC	
23	11	11316 1	SPEEDNUT	1	ELECTRIC	
24		823593A 1	AIR DEFLECTOR KIT	1		
25	37	855577 8	DECAL-EPA INFO (TOP COWL INT)	1	(1998) (SEE NOTE)	
26		813546 2	COWL MOUNT	3		
27		18173	BRACKET	1		
28	10	40067 31	SCREW (M6 X 16)	2		
29	2197	812512A 8	BOTTOM COWL ()	1	BLACK	3
29	2197	812512A 9	BOTTOM COWL ()	1	GRAY	3
30		813607	SEAL	1		
31		828465	BUMPER	2		