



7474

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	2116	7715A 4	BOTTOM COWL ASSEMBLY	1	(Black)	
1	2116	7715A 5	BOTTOM COWL ASSEMBLY	1	(Gray)	
2		88926T	COVER, Bottom Cowl	1	(Electric)	
3	10	28636	SCREW, (.250-20 x .750), Plug to	2	(Electric)	
2A		94880 1	PLUG, Bottom Cowl	1	(Manual)	
3A	10	28636	SCREW, (.250-20 x .750), Plug to E	2	(Manual)	
4	16	56766	STUD, (1/4 X 1-3/8 Inch), Bottom	4		
5	11	20184	NUT, Bottom Cowl Stud	4		
6	22	78279	ELBOW, Tell Tale Hose - Cylinder E	1		
7	32	75680 54	HOSE, Tell Tale Hose to Bottom Cc	1		
8		69791	NOZZLE, Tell Tale Hose to Bottom	1		
9	23	90882	SLEEVE, Tell Tale Nozzle	1		
10	54	90077	STA-STRAP, Tell Nozzle	AR		
11		66849	CLAMP, Nozzle - Tell Tale	1		
12	10	48408	SCREW, (#10-16 x .500), Nozzle C	1		
13		72020 1	BRACKET, Rear Support	1		
14	25	52723	GROMMET, Rear Support Bracket	1		
15		60577	MOUNT, Rubber - Rear Support Br	2		
16	12	21631	WASHER, Rubber Mount	AR		
17	11	29598	NUT, (.250-28), Rubber Mount	2		
18		72466	DRIP TRAY	1		
19	10	48409	SCREW, (#10-16 X 5/8 Inch), Drip	3		
20		37695	BOOT, Control Cable	1		
21	13	26992	LOCKWASHER, (.250), Rubber Mc	2		
22	87	69508A31	STOP SWITCH	1	(Manual Push Button Switch)	
23	87	99525A 1	COVER ASSEMBLY, Top Switch	1	(Manual Push Button Switch)	
24	11	69844	NUT, Stop Switch	1	(Manual Push Button Switch)	
25	84	62190A 8	WIRE ASSEMBLY, Orange Stop S	1	(Manual Push Button Switch)	
26		88238A 4	GROUND STRAP (3.375 Inch)	2		
27	10	62568	SCREW, (10-16 x .375), Ground Sti	2		
28		42660A 1	BRACKET ASSEMBLY, Front Supp	1		
29		31014	MOUNT, Rubber - Front Support Br	2		
30	13	26992	LOCKWASHER, (.250), Rubber Mc	2		
31	11	29598	NUT, (.250-28), Rubber Mount	2		
32	10	37562	SCREW, (.312-18 X 1.00), Front Su	2		
33		58124A20	SWITCH ASSEMBLY, Mercury	1	(Manual)	
33	87	33386A 3	SWITCH ASSEMBLY, Mercury	1	(Electric)	
34	10	69235	SCREW, Switch to Front Bracket (C	1		
35	17	36242	ROLL PIN, Mercury Switch	2		
36		45315	TERMINAL BLOCK	1	(Manual Only)	
37	10	20411	SCREW, (.180-24 x .62), Terminal	1	(Manual Only)	