



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	103	1836A 1	BOTTOM COWL ASSEMBLY	1,....		
1	103	1838A 1	BOTTOM COWL ASSEMBLY	1,1,1,1		
2		29206	COVER, PLUG-BOTTOM COWL	1,1,1,1		8
3	10	26128	SCREW, PLUG COVER TO BOT	4,4,4,4		8
4	13	26995	LOCKWASHER, PLUG COVER F	4,4,4,4		8
5	11	26419	NUT, PLUG COVER FASTENING	4,4,4,4		
6		23760	BAFFLE, BOTTOM COWL	1,1,1,1		
7	10	21106	SCREW, BAFFLE TO BOTTOM CC	3,3,3,3		
8		29229A 1	TRIM MOULDING ASSEMBLY (CH	1,1,1,1		
9	10	29226	SCREW, DECORATIVE-MOULD	5,5,5,5		
10	12	24671	WASHER, FIBRE-MOULDING FA	4,4,4,4		
11	11	29225	NUT, NYLON CAP-MOULDING F	4,4,4,4		
12	13	26995	LOCKWASHER, MOULDING FA	1,1,1,1		
13	11	26419	NUT, BRASS-MOULDING FASTI	1,1,1,1		
14	27	20390	GASKET, POWERHEAD TO BOT1	1,1,1,1		
15		30109	GROUND STRAP, CYLINDER BLC	1,1,1,1		
16		20557	BRACKET, CABLE END ANCHOR	2,2,2,2		
17	10	29200	SCREW, ANCHOR BRACKET TO	4,4,4,4		
18		29532	LEVER, THROTTLE CONTROL	1,1,1,1		
19		29824	LEVER, SHIFT CONTROL	1,1,1,1		
20	23	29529	BUSHING, THROTTLE AND SHIF	2,2,2,2		
21	12	29395	WASHER, THROTTLE AND SHIF	4,4,4,4		
22	10	26632	SCREW, THROTTLE AND SHIF	2,2,2,2		
23	17	30978A 1	PIN ASSEMBLY, CLEVIS YOKE	2,2,2,2		
24	17	23928	ROLL PIN, CLEVIS YOKE PIN	2,2,2,2		
25	10	20584	SCREW, CLEVIS YOKE PIN TO LE	2,2,2,2		
26	13	29402	WASHER, WAVE-CLEVIS PIN FAS	2,2,2,2		
27	11	29488	NUT, CLEVIS PIN FASTENING SC	2,2,2,2		
28		25180	SHIFT SHAFT ASSEMBLY, UPPEF	1,1,1,1		
29		27714	ROD (SLEEVE), SHIFT CONTROL	1,1,1,1		
30	11	25168	NUT, ADJUSTING-SHIFT SHAFT	1,1,1,1		
31		25134	ROD, LINK-SHIFT SHAFT END	1,1,1,1		
32	18	25191	COTTER PIN, LINK ROD TO SHIF	2,2,2,2		
33	12	20583	WASHER, SHIFT CONTROL END	1,1,1,1		
34	24	25065	SPRING, DETENT-SHIFT SHAFT	1,1,1,1		
35	10	20776	SCREW, DETENT SPRING TO BC	1,1,1,1		
36	12	20346	WASHER, DETENT SPRING SCR	1,1,1,1		
37	11	20013	NUT, DETENT SPRING FASTENII	1,1,1,1		
38	32	29164	TUBE, VENT-MAGNETO OUTLET	2,2,2,2		
39	22	25885	ELBOW, MAGNETO VENT TUBE	1,1,1,1		
40	22	29111	NIPPLE, MAGNETO VENT TUBE	1,1,1,1		