



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	22339	NUT, FLYWHEEL	1,1,1,1		
2	12	26617	WASHER, FLYWHEEL NUT	1,1,1,1		
3	28	20094	KEY, FLYWHEEL DRIVE	1,1,1,1		
4	400	1730	CRANKSHAFT	1,1,1,1		
5	25	29619	"O" RING, DRIVE SHAFT SPLINE	1,1,1,1		
6	500	1030A 1	CENTER MAIN BEARING ASSEM	1,1,1,1		
7	17	20032	DOWEL PIN, CENTER MAIN BE	2,2,2,2		
8	29	20046	BEARING, NEEDLE	28,28,2		
9		20047	RACE, OUTER	1,1,1,1		
10	53	20048	RING, SNAP - OUTER RACE C	1,1,1,1		
11	10	20482	SCREW, CENTER MAIN BEARIN	2,2,2,2		
12	17	20379	DOWEL PIN (STEPPED)	1,1,1,1		
13	527	1619A 1	MAIN BEARING ASSEMBLY (VAL)	2,2,2,2		
14	17	20032	DOWEL PIN, MAIN BEARING	20,20,2		
15	10	20049	SCREW, MAIN BEARING CLAM	4,4,...		
16	11	25313	SCREW, MAIN BEARING CLAM	4,4,4,4,		
17	34	29469	NUT, MAIN BEARING CLAMPIN	4,4,4,4,		
18	34	20888A 1	REED SET, MATCHED - MAIN BE	2,2,2,2		
18	34	20053	REED STOP,, MAIN BEARING RE	8,8,8,8,		
--	12	26014	WASHER, REED STOP MOUNTIN	8,8,8,		
19	10	20055	SCREW, REED STOP MOUNTING	8,8,8,		
19	10	29465	SCREW, REED STOP MOUNTING	8,8,8,8,		
20	11	29469	NUT, REED STOP MOUNTING SC	8,8,8,8,		
21	724	1631A 2	PISTON AND PISTON PIN ASSEM	4,4,4,4,		
22	40	20057	LOCK RING, PISTON PIN	8,8,8,8,		
23	39	27841	RING, PISTON	12,12,1		
24	600	7A 4	CONNECTING ROD AND CAP AS'	4,4,4,4,		
25	10	20060	SCREW, CAP TO CONNECTING	8,8,8,8,		
26	11	20061	NUT, CONNECTING ROD SCRE	8,8,8,8,		
27	29	20046	BEARING, NEEDLE - CRANKPIN	100,100		
28	29	20063	BEARING, NEEDLE - PISTON PI	88,88,8		
29			WASHER, NEEDLE LOCATION	8,8,8,8,		
--	724	1663A 1	PISTON AND PISTON PIN ASSEM	4,4,4,4,		
--	39	28616A12	RING, PISTON (OVERSIZED .015	12,12,1		