



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1427	1810A 1	CLAMP BRACKET ASSEMBLY (N)	2,		
1	1440	1797A 1	CLAMP BRACKET ASSEMBLY	2,2		
2		22477A 1	THUMB SCREW ASSEMBLY	2,		
2		28403A 3	THUMB SCREW ASSEMBLY	2,2		
3	12	26227	WASHER, THUMB SCREW	2,		
3	12	28404	WASHER, THUMB SCREW	2,2		
4		30664	TUBE, TILT - CLAMP BRACKET T	1,1,1		
5	15	30497A 1	SHIM, CLAMP BRACKET TO SWI	2,2,2		
6	11	30499	NUT, TILT TUBE FASTENING	2,2,2		
7		30498	CAP, PLASTIC - TILT TUBE ENDS	2,2,2		
8	16	20221	STUD, CLAMP BRACKET	1,1,1		
9	23	20222	SPACER, CLAMP BRACKET STUC	1,1,1		
10	13	26393	LOCKWASHER, CLAMP BRACKET	2,2,2		
11	11	20083	NUT, STUD TO CLAMP BRACKET	2,2,2		
12	17	29219A 1	TILT LOCK PIN ASSEMBLY	1,1,1		
13		26903A 3	REVERSE LOCK ASSEMBLY	1,1,1		
14	18	20209	COTTER PIN, REVERSE LOCK TO	1,1,1		
15	24	29821	SPRING, TENSION - REVERSE LO	1,1,1		
16	17	25598	ROLL PIN, REVERSE LOCK SPRIN	1,1,1		
17		20208	SHAFT, REVERSE LOCK TO SWI	1,1,1		
18	1401	1977A 1	SWIVEL BRACKET ASSEMBLY	1,	SERIAL 00000(1)-01507833	
18	1401	1822A 1	SWIVEL BRACKET ASSEMBLY	1,	SERIAL J1507834-09999999	
18	1442	2183A 1	SWIVEL BRACKET ASSEMBLY	.1,1		
19	22	23612	FITTING, GREASE - SWIVEL BF	1,1,1		
20	26	26209	OIL SEAL, SWIVEL BRACKET	2,	SERIAL 00000(1)-01507833	
20	26	32911	OIL SEAL, SWIVEL BRACKET	2,2,2	SERIAL J1507834-09999999	
21		29359	LUBRICAP, SWIVEL BRACKET Gf	1,1,1		
22		20215	LEVER, TILT STOP - STARBOARD	1,		
23		26864	LEVER, TILT STOP - PORT SIDE	1,		
22		29057	LEVER, TILT STOP - STARBOARD	.1,1		
23		29056	LEVER, TILT STOP - PORT SIDE	.1,1		
24	10	20217	SCREW, ANCHOR - TILT STOP LI	2,		
24	10	29054	SCREW, ANCHOR - TILT STOP LI	2,2		
25	23	20216	SPACER, TILT STOP LEVER	2,		
25	23	29055	SPACER, TILT STOP LEVER ANC	2,2		
26	10	29237	SCREW, RETAINING - TILT STOF	2,		
26	10	27790	SCREW, RETAINING - TILT STOF	2,2		
27	15	20473	SHIM, RETAINING SCREW - POR	1,1,1		
28	13	20846	WASHER, WAVE - RETAINING SI	1,1,1		
29	11	24652	NUT, ANCHOR AND RETAINING	4,4,4		
30	12	27964	WASHER, SWIVEL PIN TO ROT	AR		