



Parts List							
Ref	Class	Part	Description	Qty	Comment	Footnote	
1	1522	1567	DRIVE SHAFT HOUSING	1,1			
2	32	31117	TUBE, WATER INLET	1,1			
3	26	25192	SEAL, WATER INLET TUBE	1,1			
4	23	23651	SLEEVE, WATER INLET TUBE	1,1			
5	27	24899	GASKET, DRIVE SHAFT HOUSING	1,1			
6	11	25594	NUT, POWERHEAD STUDS	8,8			
7	10	25093	SCREW, GEAR HOUSING TO DRIVE SHAFT	1,1			
8	16	29103	STUD, DRIVE SHAFT HOUSING TO GEAR HOUSING	1,1			
9	11	22178	NUT, GEAR HOUSING AND DRIVE SHAFT HOUSING	3,3			
10		28470	ROD, PUSH-REVERSE LOCK	1,1			
11	17	24887	PIN, REVERSE LOCK LEVER	1,1			
12	18	25191	COTTER PIN, PUSH ROD	1,1			
13	24	25122	SPRING, TENSION-PUSH ROD	1,1			
14		25140	LEVER, REVERSE LOCK	1,1			
15		24926	MOUNT, RUBBER-UPPER	2,2			
16		24935	COVER, UPPER MOUNT-OUTSIDE	2,2			
17		31120	COVER, UPPER MOUNT-INSIDE	2,2			
18		24929	PACKING, "U" CUP	2,2			
19	12	24889	WASHER, UPPER MOUNT BOLT	2,2			
20	12	24891	WASHER, RUBBER-UPPER MOUNT BOLT	2,2			
21	23	30474	SPACER, UPPER MOUNT BOLT	2,2			
22	12	30473	WASHER, UPPER MOUNT BOLT	2,2			
23	11	23161	NUT, UPPER MOUNT BOLT	2,2			
24		25305	CAP, RUBBER-UPPER MOUNT BOLT	2,2			
25	10	28772	SCREW, UPPER MOUNT COVER	4,4			
26	10	31114	SCREW, UPPER MOUNT COVER	4,4			
27	12	29245	WASHER, MOUNTING COVER SCREW	8,8			
28	11	29322	NUT, MOUNTING COVER SCREW	8,8			
29		24925	MOUNT, RUBBER-LOWER	2,2			
30	12	28053	WASHER, RUBBER-LOWER MOUNT BOLT	2,2			
31	12	28051	WASHER, LOWER MOUNT	2,2			
32	12	30119	WASHER, MOUNTING SCREW (LOWER MOUNT)	2,2			
33	11	25096	NUT, MOUNTING SCREW	2,2			
34	10	30452	SCREW, LOWER MOUNT (5 1/2" LONG)	2,2			
35		25067	BUMPER, RUBBER-MOUNTING SCREW	2,2			
36		28241	COVER, LOWER MOUNT (PORT)	1,1			
36		28242	COVER, LOWER MOUNT (STARBOARD)	1,1			
37	10	29256	SCREW, LOWER MOUNT COVER	6,6			
38	22	21290	PLUG, GREASE-REVERSE LOCK	1,1			