



TOP COWL AND STARTER ASSEMBLY

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	191	5231A 4	TOP COWL ASSEMBLY	1	UNITED STATES 4597261 AND I	
1	191	6189A 2	TOP COWL ASSEMBLY	1	UNITED STATES 4597262 AND I	
2		39538	STRIP, SOUND SEAL - REAR	1		
3		39537	STRIP, SOUND SEAL - FORWARD	1		
4		66018	MOUNT, RUBBER - TOP COWL	2		
5		63170	COVER, TRIM - TOP COWL	1		
6	10	64652	SCREW, TRIM COVER TO TOP C	1		
7	14	20165	TAB WASHER, SHEAVE SHAFT	1		
8	11	20166	NUT, SHEAVE SHAFT (LEFT HAN	1		
9		64601	COVER, VENT - COP COWL	1		
10	10	35519	SCREW, VENT SCREEN TO TOP	2		
11		39257	BRACKET, PORT - TOP COWL FA	1		
11		39258	BRACKET, STARBOARD - TOP C	1		
12	10	39514	SCREW, BRACKET TO TOP COW	4		
13	12	39143	WASHER, BRACKET SCREW (1/	4		
13		20155	RETAINER, STARTER SPRING	1		
15	24	29340A 1	SPRING ASSEMBLY, STARTER F	1		
16	23	28912	BUSHING, SPRING GUIDE	1		
17	50	74346A 1	STARTER SHEAVE ASSEMBLY	1		
18	17	22896	PIN, RETAINER - STARTER C	1		
19		30596	PAWL, STARTER	3		
20	13	36206	WASHER, WAVE - STARTER PA	3		
21	23	28919	BUSHING, NYLON - SHEAVE SHA	1		
22	23	61005	SPACER, SHEAVE SHAFT	1		
23		26179	RETAINER, SHEAVE SHAFT TO	1		
24	12	35559	WASHER, SHEAVE SHAFT RETA	1		
25	13	20160	WASHER, WAVE - RETAINER TE	1		
26		30595	PLATE, RETAINER - STARTER P	1		
27		35558	SHAFT, SHEAVE	1		
28		55860	PULLEY, STARTER CABLE	1		
29	23	30977	SPACER, CABLE PULLEY	1		
30	12	22887	WASHER, PULLEY FASTENING	1		
31	10	28789	SCREW, PULLEY TO TOP COWL	1		
32	50	61575A 1	STARTER CABLE ASSEMBLY	1		
33		28748	RETAINER, STARTER CABLE	1	UNITED STATES 4869517 AND I	
34		30782	HANDLE, STARTER CABLE	1	UNITED STATES 4869517 AND I	
33		77997A 1	RETAINER ASSEMBLY, STARTER	1	UNITED STATES 4869518 THRL	
34		77998	HANDLE, STARTER CABLE	1	UNITED STATES 4869518 THRL	
33		79470A 1	HANDLE AND RETAINER ASSEM	1	UNITED STATES 5270784 AND I	