



5327

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	1258	824964A	2 FUEL TANK	1		
2	36	824962A	2 CAP	1		
3	26	16235	2 SEAL	1		
4		16236	1 MOUNT	3		
5	12	95392	1 WASHER	2		
6	13	40025	6 LOCKWASHER, (M6)	5		
7	11	40021	2 NUT, (M6)	5		
8	12	16238	1 WASHER	3		
9		16239	1 BRACKET	1		
10	10	16832	2 BOLT, (M6 x 16)	2		
11	13	40025	6 LOCKWASHER, (M6)	2		
12	22	815043	1 REDUCER ELBOW	1		24
13	22	815045	1 FUEL COCK	1		24
14	10	815046	2 SCREW	2		24
15		56762	1 CABLE TIE, (4.00 Inch)	1		24
16	32	95394	9 FUEL LINE	2	(4 HP)	24
16	32	95394	9 FUEL LINE	3	(5 HP)	
17	35	16248	1 FILTER, Fuel	1		24
18	54	95395	5 CLIP	5	(4 HP)	24
18	54	95395	11 CLIP	11	(5 HP)	
19	22	73318	1 TEE (5 HP)	1		
20	32	815049	1 HOSE (5 HP)	1		
21	22	815048	1 CONNECTOR (5 HP)	1		
22	32	815041	1 HOSE (5 HP)	1		
23	22	15781A	5 FUEL CONNECTOR (5 HP)	1		
24	10	40003	33 SCREW, (M6 x 40) (5 HP)	1		
25	12	16826	1 WASHER (5 HP)	1		
26	22	15781A	5 FUEL CONNECTOR (5 HP)	1		
27	10	40003	33 SCREW, (M6 x 40) (5 HP)	1		
28	12	16826	1 WASHER (5 HP)	1		
29	54	95395	4 CLIP (5 HP)	4		
30	32	17668	1 HOSE (5 HP)	1		
31	54	813275	2 CLAMP (5 HP)	2		
32	35	16248	1 FILTER, Fuel (5 HP)	1		
33	32	17669	1 HOSE (5 HP)	1		
-		815045A	1 FUEL SHUT-OFF KIT (4 HP)	1		