



14458

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	262	803557T01	FLYWHEEL	1		
1	262	803557T02	FLYWHEEL	1	(Sailpower/Sailmate)	
2	339	803559T07	IGNITER ASSEMBLY	1		
3	10	823042 24	BOLT	2		
4	85	803560	BOOT	1		
5	85	803560003	PROTECTOR	1		
6	10	16123	SCREW, (25mm)	4		
7	12	16080	WASHER	4		
8	54	16060	CLAMP	1		
9	10	16821	SCREW	1		
10		16074T04	ALTERNATOR	1	(Sailpower/Sailmate-Standard)	
11	54	95306	CLAMP	1		
12	10	823042 7	BOLT	1		
13	54	95395 1	CLAMP	1		
14	10	823042 7	BOLT	1		
15		803562	WARNING LAMP	1		
16	87	823037A06	SWITCH ASSEMBLY, Stop-Lanyar	1		