



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-		812632A 3	RECOIL STARTER ASSEMBLY	1		
1		812632	STARTER HOUSING	1		
2	24	812645T	SPRING SET, Starter	1		
3		812633	STARTER SHEEVE	1		
4	24	812634	RETURN SPRING	2		
5		812635	RATCHET	2		
6	24	812636	FRICTION SPRING	1		
7	10	812637	BOLT	1		
8		812638	FRICTION PLATE	1		
9		16110 1	SEAL PLATE	1		
10	50	120660 9	ROPE	1		
11		812640	STARTER HANDLE	1		
12	25	812641	RETAINER	1		
13		812642	STARTER PULLEY	1		
14	10	16828 1	SCREW, (with Lockwasher)	3		
15	10	810755	SCREW	3		
16		17634	STARTER LOCK	1		
17	23	17637	COLLAR	1		
18	24	17638	SPRING	1		
19	10	855544 9	SCREW	1		
20		17643 1	ROD SNAP	2		
21		812643 1	STARTER LOCK CAM	1		
22	10	804364	SCREW	1		
23	23	804365	COLLAR	1		
24	24	804366	SPRING	1		
25	12	16826	WASHER	2		
26		17642001	ROD	1		
27	13	40025 6	LOCKWASHER, (M6)	3		