



534A

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1682	821306T26	GEAR HOUSING	1	(Black)(Short)	
-	1682	821306T28	GEAR HOUSING	1	(Black)(Long)	
1	1682	821306T12	GEAR HOUSING, (Basic)	1	(Basic-Black)	
40	17	821327	PIN, Dowel	2		
41	27	823942	GASKET	1		2
42	32	821828	TUBE	1		
43	19	824928	PLUG, Rubber	1		
44		821829	SCREEN	1		
45		822157T 2	TRIM TAB	1		
46	10	824970 20	SCREW, (M8 x 20)	1		
47	12	72397	WASHER	1		
48	43	822162T 2	FORWARD GEAR (22 Teeth)	1		
49	31	99328A 1	ROLLER BEARING ASSEMBLY	1		
50		NSS	NOT SOLD SEPARATE	1	(Cup)	
51	31	41326	ROLLER BEARING	1		
52		821578	FOLLOWER, Cam	1		
53	24	826199 1	SPRING	1		
54	17	85093	PIN	1		
55	52	821314T	CLUTCH	1		
56	24	38114	SPRING	1		
57	44	821577 2	PROPELLER SHAFT	1		
58	43	822163T 1	REVERSE GEAR (22 Teeth)	1		
59	30	20839T	BEARING	1		
60		19291A 3	BEARING CARRIER	1		
61	25	815460	O-RING	1		2,15
62	31	21700	BEARING, Needle	1		
63	26	69188	OIL SEAL	1		15
64	26	69189	OIL SEAL	1		15
65	12	70132	WASHER, (.323 x .563 x .063) St	2		
65	12	855941	WASHER	2	(Use with Threaded Insert)	
66	10	40003 53	SCREW, (M8 x 25)	2		
66	10	855940 30	SCREW, (M8 x 30)	2	(Use with Threaded Insert)	
67		822773 1	INSERT, Threaded	2		
68		NSS	NOT SOLD SEPARATE (Decal 1.8)	1		
69		73345A 1	THRUST HUB	1		
70	11	69578Q 1	PROP NUT KIT	1		
71	14	76281	TAB WASHER	1		
72	10	40003 80	SCREW, (M10 x 45)	4		
73	12	856774	WASHER, (.406 x .750 x .105)	4		
-	27	828553A97	GASKET SET	1		
-		822547A 2	SEAL KIT	1		