

Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|------|------------------------------|-----|---------|----------|
| 1 | 392 | 8848 | MOTOR DRIVE | 1 | | |
| 2 | 392 | 8852 | PLATE ASSEMBLY, DRIVE END | 1 | | |
| 3 | 392 | 8853 | BUSHING, DRIVE END PLATE | 1 | | |
| 4 | 392 | 8847 | ARMATURE | 1 | | |
| 5 | 392 | 8856 | PACKAGE, ARMATURE THRUST | 1 | | |
| 6 | 392 | 8849 | END CAP ASSEMBLY, COMMUTA | 1 | | |
| 7 | 392 | 8850 | BRUSH PLATE AND HOLDER A | 1 | | |
| 8 | 392 | 8851 | BRUSH AND TERMINAL SET | 1 | | |
| 9 | 392 | 8854 | SPRING SET, BRUSH (2 SPRING: | 2 | | |
| 10 | 392 | 8855 | BOLT, THRU - END CAP TO END | 1 | | |

