



| Parts List | | | | | | |
|------------|-------|-----------|------------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 816728 | STARTER HOUSING | 1 | | |
| 2 | | 816765 | REST | 1 | | |
| 3 | | 813607 | SEAL | 1 | | |
| 4 | 10 | 821704 | SCREW | 2 | | |
| 5 | 23 | 821702 | SPACER | 2 | | |
| 6 | 23 | 816086 | BUSHING | 4 | | |
| 7 | 25 | 815795 | GROMMET | 8 | | |
| 8 | 12 | 69057 | WASHER | 8 | | |
| 9 | 11 | 40119 | NUT | 4 | | |
| 10 | | 816748 | INTERLOCK CABLE | 1 | | |
| 11 | 10 | 821428 | SCREW | 1 | | |
| 12 | 12 | 73288 | WASHER | 1 | | |
| 13 | 18 | 27769 | COTTER PIN | 1 | | |
| 14 | 10 | 812832 | SCREW | 1 | | |
| 15 | 11 | 821027 | PUSH NUT (DESIGN I) | 1 | | |
| 15A | 18 | 27769 | COTTER PIN (DESIGN II) | 1 | | |
| 15B | 12 | 35462 | WASHER (DESIGN II) | 1 | | |
| - | | 816728A | RECOIL STARTER (S/N OG23916) | 1 | | |
| - | | 816728A10 | RECOIL STARTER (S/N OG23916) | 1 | | |
| 16 | 24 | 826791 | SPRING | 1 | | |
| 17 | | 816690 | INTERLOCK LEVER | 1 | | |
| 18 | | 816712 | CAM | 1 | | |
| 19 | | 816711 | RETAINER | 1 | | |
| 20 | 10 | 818249 | SCREW | 3 | | |
| 21 | | 90478 | FELT PAD (DESIGN I) | 1 | | |
| 21A | 13 | 826229 | WASHER - SPRING (DESIGN II) | 1 | | |
| 22 | 24 | 86857 | SPRING | 1 | | |
| 23 | 50 | 825269 | STARTER SHEAVE | 1 | | |
| 24 | 24 | 86851 | SPRING | 2 | | |
| 25 | | 86850 | CAM | 2 | | |
| 26 | 53 | 86849 | RETAINING RING | 2 | | |
| 27 | 50 | 12066A | STARTER ROPE | 1 | | |
| 28 | | 85174A | HANDLE ASSEMBLY | 1 | | |
| 29 | 24 | 86852 | SPRING | 1 | | |
| 30 | | 86853 | CAM | 1 | | |
| 31 | 10 | 826253 | SCREW | 1 | | |
| 32 | | 42690 | BUSHING | 1 | | |
| 33 | 53 | 818853 | RETAINING RING | 1 | | |