

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	392	8848	MOTOR DRIVE	1		
2	392	8852	PLATE ASSEMBLY, DRIVE END	1		
3	392	8853	BUSHING, DRIVE END PLATE	1		
4	392	8847	ARMATURE	1		
5	392	8856	PACKAGE, ARMATURE THRUST	1		
6	392	8849	END CAP ASSEMBLY, COMMUTA	1		
7	392	8850	BRUSH PLATE AND HOLDER A	1		
8	392	8851	BRUSH AND TERMINAL SET	1		
9	392	8854	SPRING SET, BRUSH (2 SPRING:	2		
10	392	8855	BOLT, THRU - END CAP TO END	1		

