



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		73641A 1	BRACKET, TOP (MERCURY)	1		
1		73641A 2	BRACKET, TOP (MARINER)	1		
2		62444	SEAL, RUBBER - TOP BRACKET/	1		
3		79652	CLIP, SUPPORT BRACKET	1		
4	10	48409	SCREW, CLIP TO SUPPORT (1/2"	1		
5		79490T	SHIELD, FLYWHEEL	1		
6	10	37656	SCREW, SHIELD TO SUPPORT B	1		
7	10	48408	SCREW, SHIELD TO SUPPORT B	3		
8		91891	WEAR PLATE, SOUND ATTENUA	2		
9		74510A 2	BRACKET, COWL SUPPORT - RE	1		
10		69876 1	SEAL, REAR BRACKET AND TOP	4		
11		90435	MOUNT, RUBBER - REAR SUPP	1		
12	12	20346	WASHER, RUBBER MOUNT	2		
13	11	20184	NUT, RUBBER MOUNT	2		
14		26901	STOP, RUBBER - REAR SUPPOR	3		
15		60116	BRACE, COWL SUPPORT BRACK	1		
16	10	76596	SCREW, SUPPORT BRACKET (1-	3		
17		90435	MOUNT, RUBBER - FRONT SUPP	1		
18	11	36069	NUT, RUBBER MOUNT	2		
19		71097	BRACKET, RUBBER MOUNT	1		
20	10	59645	SCREW, BRACKET TO CRANKCA	1		
21		97348	ATTENUATOR, SOUND	1		
22		88684	COVER, MANUAL CHOKE	1		
23	10	23015	SCREW, COVER TO TOP COVER	2		
24	12	53705	WASHER, COVER SCREW	1		
25		73986	AIR MANIFOLD	1		
26	10	69093	SCREW, AIR MANIFOLD	2		
27		90435	MOUNT, RUBBER - FRONT SUPP	1		
28	11	20184	NUT, RUBBER MOUNT	2		
29		76410	SEAL, FUEL CONNECTOR - SOU	1		
30		76578	COVER, SOUND ATTENUATOR (I	1		
31	10	37571	SCREW, FRONT COVER (1/2")	8		
32	19	73336	PLUG, FRONT COVER	2		
33		76251A 1	PLATE ASSEMBLY, FRONT COVE	1		
34		76264	LATCH, FRONT COVER	1		
35	24	60295	SPRING, FRONT COVER LATCH	1		
36	10	28635	SCREW, COVER PLATE TO SUPP	3		
37		87764	BRACKET, REAR - LOWER MOUN	1		
38	10	76596	SCREW, REAR BRACKET ATTAC	3		
39		90435	MOUNT, RUBBER - REAR COWL	1		
40		88228A 2	GROUND STRAP ASSEMBLY	1		