



SHIFT LINKAGE AND EXHAUST PLATE

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		91951	BRACKET, ANCHOR - CONTROL	1	
2		60283A	LINK ASSEMBLY, SHIFT SHAFT	1	
3	24	20099	SPRING, LINK TO ANCHOR BRAC	1	
4		37896	GUIDE BLOCK, LINK	1	
5		52100	WEAR PLATE, NYLON - LINK	1	
6		38279	LATCH, LINK TO ANCHOR BRAC	1	
7	12	35462	WASHER, LINK LATCH	1	
8	11	36069	NUT, LINK ATTACHING	2	
9		75355A30	SHIFT SHAFT ASSEMBLY, UPPE	1	
9		75355A32	SHIFT SHAFT ASSEMBLY, UPPE	1	
10	13	29720	WASHER, WAVE - SHIFT SHAFT	1	
11	23	26856	BUSHING, NYLON - SHIFT SHAF	1	
12	12	35462	WASHER, LINK (SHIFT SHAFT E	1	
13		39519	CUP, RETAINER - ANCHOR BRAC	1	
14		39618	LEVER, NYLON - SHIFT CABLE LI	1	
15	17	47175	PIN, LOCKING LEVER AND COVE	3	
16		65799	LINK, LOCKING LEVER TO COVE	1	
17		90211	COVER, NYLON - SHIFT CABLE	1	
18	10	69101	SCREW, ANCHOR BRACKET (7/E	3	
19	27	88451	GASKET, POWERHEAD	1	5
20		42869A	EXHAUST PLATE ASSEMBLY	1	
21	23	27132	BUSHING, NYLON - EXHAUST P	1	
22	16	69058	STUD, EXHAUST PLATE (1-11/	1	
23	16	68166	STUD, EXHAUST PLATE (2-1/8'	1	
24	26	38452	SEAL, WATER INLET TUBE	1	5
25	12	38453	WASHER, NYLON - WATER SE	1	
26		79799	HOUSING, WATER SEAL	1	
27	27	79797	GASKET, HOUSING	1	5
28	10	79798	SCREW, HOUSING TO EXHAUS	2	
29		60307	SEAL, EXHAUST PLATE	1	
30		60306	STRIP, RETAINING - EXHAUST	1	
31	10	62568	SCREW, RETAINING STRIP (3/	4	
32	10	22411	SCREW, EXHAUST PLATE (1")	4	
32	10	28668	SCREW, EXHAUST PLATE (7/8")	1	
33	27	38501	GASKET, ADAPTOR PLATE	1	5
34		58911	EXHAUST TUBE, ADAPTOR (50)	1	
34		42718	EXHAUST TUBE, ADAPTOR (60)	1	
35	27	60280	GASKET, EXHAUST TUBE	1	5
36	10	28636	SCREW, EXHAUST TUBE (3/4")	3	
-	27	88449A32	GASKET SET	1	