



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		48416	CAP, STEERING HANDLE GRIP	1	
2	11	20586	NUT, STEERING HANDLE ARM	1	
3	12	21631	WASHER, STEERING HANDLE A	1	
4		58192A 1	GRIP, STEERING HANDLE ARM	1	
5		48414	HOUSING, DRIVE WHEEL	1	
6		48516A 1	DRIVE WHEEL AND ROD ASSEM	1	
7		48405	ARM (USE WITH PUSH BOTTON	1	
7		48405A 2	ARM (USE WITH TOGGLE SWITC	1	
8		48519	PLATE, COVER - DRIVE WHEEL	1	
9	27	48518	GASKET, COVER PLATE	1	
10	10	28192	SCREW, DRIVE WHEEL COVER F	4	
11		78551 1	CABLE CONDUIT	1	
12		48520	THROTTLE CABLE	1	
13		89613	CONNECTOR, CONTROL LINKAG	1	
14	10	89601	SCREW, SET - THROTTLE CABLE	1	
15		89566	TUBE, THROTTLE CABLE GUIDE	1	
16		29880	GUIDE, THROTTLE CABLE	1	
17		20007	ANCHOR, THROTTLE CABLE	1	
18	10	20518	SCREW, THROTTLE CABLE ANC	2	
19		48404	BRACKET, HANDLE	1	
20		48416	CAP, HANDLE BRACKET	1	
21	10	48476	SCREW, HANDLE BRACKET	1	
22	12	48477	WASHER, HANDLE BRACKET (.5	1	
23	12	48526	WASHER, NYLON - HANDLE BRA	1	
24	23	28919	BUSHING, NYLON - HANDLE BRA	2	
25	23	48525	SPACER, HANDLE BRACKET	1	
26	12	48527	WASHER, NYLON - HANDLE BRA	1	
27	13	48478	WAVE WASHER, HANDLE BRACI	2	
28	12	49636	WASHER, NYLON - HANDLE BRA	1	
29	11	20220	NUT, HANDLE BRACKET SCREW	1	
30	10	35786	SCREW, BRACKET TO ENGINE (	2	
31	14	43589	TAB WASHER, BRACKET SCREW	2	
32		78812A 1	DETENT, SHIFT LEVER	1	
33	10	48409	SCREW, SHIFT LEVER DETENT	2	
34		48568 1	SHIFT LEVVER	1	
35	23	48237	BUSHING, NYLON - SHIFT LEVEF	1	
36	12	34931	WASHER, SHIFT LEVER	1	
37	11	34863	NUT, SHIFT LEVER	1	
38		49563	SHIFT ROD	1	
39		48419	ROD END, SHIFT ROD	1	
40	22	48475	BUSHING, NYLON, SHIFT ROD C	1	