



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
-		76395A 5	HYDRAULIC PUMP ASSEMBLY, C	1			
1	28	48171	"O" RING HYDRAULIC PUMP	4			
2	392	7734	VALVE BODY AND GEAR ASSE	1			
3	10	20411	SCREW, VALVE BODY TO RESI	8			
4	392	2937	SEAL, RESEROVIR TO VALVE E	1			
5	392	2939	RESERVOIR ASSEMBLY	1			
6	10	62269	SCREW, VENT - HYDRAULIC PI	1			
7	10	79953	SCREW, FILLER - HYDRUALIC I	1			
8	12	20260	WASHER, SEALIN - FILLER SCF	1			
9	392	2623	WASHER, THRUST - ARMATUF	AR			
10	392	2943	ARMATURE, FIELD AND FRAMI	1			
11	392	2942	FIELD AND FRAME ASSEMBLY	1			
12	392	2944	BALL, COMMUTATOR END PLA	1			
13	392	2940	PLATE ASSEMBLY, COMMUTA	1			
14	392	2941	BRUSH SET, COMMUTATOR	1			
15	392	2529	SPRING SET, BRUSH TENSION	1			
16	392	2938	BOLT SET	1	THRU - PLATE AND FRAME TO		
17	13	26996	LOCKWASHER, THRU BOLT	2			