



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1592	7512A10	DRIVE SHAFT HOUSING ASSEM	1	
1	1593	7513A12	DRIVE SHAFT HOUSING ASSEM	1	
2	22	39072	PLUG, DRIVE SHAFT HOUSING	1	
3	19	64649	PLUG, PLASTIC - TRIM TAB SCI	1	
4	16	57932	STUD, DRIVE SHAFT HOUSING	1	
4	16	97460	STUD, DRIVE SHAFT HOUSING	1	
5	16	57935	STUD, DRIVE SHAFT HOUSING	1	
5	16	96124	STUD, DRIVE SHAFT HOUSING	1	
6	12	65791	WASHER, GEAR HOUSING STUC	2	
7	11	34933	NUT, GEAR HOUSING STUDS (7,	2	
8		93445	MOUNT, RUBBER - UPPER	2	
9		96401	SEAL, UPPER MOUNT	2	
10	12	27727	WASHER, UPPER MOUNT BOLT	2	
11	12	66966	WASHER, RUBBER - UPPER MOI	2	
12	12	30514	WASHER, UPPER MOUNT BOLT	2	
13	11	34933	NUT, UPPER MOUNT BOLT	2	
14		87883	COVER, UPPER MOUNT	2	
15	10	76630	SCREW, UPPER MOUNT COVER	4	
16	12	29245	WASHER, UPPER MOUNT COVE	4	
17		37687	COVER, TRIM - DRIVE SHAFT HC	1	
17		37687F 2	COVER, TRIM-DRIVE SHAFT HO	1	
18	10	57807	SCREW, TRIM COVER TO DRIVE	4	
19	25	92012	GROMMET, TRIM COVER SCREW	4	
20		38157	SEAL, TRIM COVER TO DRIVE SH	1	
21		38158	STRIP, RETAINING - TRIM COVEI	1	
22		38154	STRIP, RETAINING - TRIM COVEI	2	
23	10	48408	SCREW, RETAINING STRIP	10	
24		69543	TUBE, EXHAUST (SHORT SHAFT)	1	
24		69544	TUBE, EXHAUST (LONG SHAFT)	1	
25	32	37727	TUBE, WATER INLET (SHORT SH	1	
25	32	45679	TUBE, WATER INLET (LONG SH)	1	
25	32	98856	TUBE, WATER INLET (X-LONG SI	1	
26	11	64809	NUT, POWERHEAD STUDS (5/16	8	
27		75304	MOUNT, RUBBER - LOWER	2	
28	10	75284	SCREW, LOWER MOUNT SCREW	2	
29	12	28051	WASHER, LOWER MOUNT SCRE	2	
30	12	28053	WASHER, RUBBER - LOWER MO	2	
31	12	30119	WASHER, LOWER MOUNT SCRE	2	
32	11	25096	NUT, LOWER MOUNT SCREW	2	
33		69592	CLAMP, LOWER MOUNT	2	
34	10	28255	SCREW, LOWER MOUNT CLAMP	4	