



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		832991T 3	EXHAUST VALVE	4	6
2		832990T 3	INTAKE VALVE	4	6
3	26	858271	SEAL-VALVE STEM	8	6
4	24	858268	VALVE SPRING-OUTER	8	6
5		822650	RETAINER	8	6
6	28	822651	KEY	16	6
7		858272A 1	ROCKER ARM	8	6
8	10	825046	SCREW	8	6
9	11	858274	NUT	8	6
10		857085	ROCKER SHAFT	1	6
11		NSS	PLUG	2	6
12		859577	BRACKET	2	6
13		858275	BRACKET	1	6
14	24	825052 1	SPRING	2	6
15	10	875218	SCREW (M8 X 23)	5	6
16	27	859576	GASKET	1	6
17	17	859575	PIN-CAM THRUST	1	6
18	24	881858	SPRING-Overload	2	6
-		857082A 5	CYLINDER HEAD	1	