



6 Dielectric Grease (92-823506-1)  
 9 Loctite PST Pipe Sealant (92-809822)

**NOTE: APPLY LIQUID NEOPRENE TO ALL EYELET WIRING TERMINAL CONNECTIONS.**

ELECTRICAL COMPONENTS

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	10	40011128	SCREW (M6 X 20)	2		
2		825098	ELECTRIC CONTROLLER	1	(50)	
2		825098	ELECTRIC CONTROLLER	1	(40/45)	
3		834791	BRACKET	1	(S/N-0G472133 & UP)	
4		834791	BRACKET	1	(BIGFOOT)	
5		825092	STAY	2	S/N-0G472132 & BELOW	
6		825094	STARTER BRACKET	1	S/N-0G472132 & BELOW	
7	10	818934	SCREW (M8 X 35)	4		
8		825074	SOLENOID PLATE	1		
9	10	824832	SCREW (M6 X 16)	1		
10	11	826833	NUT	2		
11	89	825096	STARTER SOLENOID	1		
12		95643M	BRACKET	1		
13		825076	VOLTAGE REGULATOR	1		
14	10	824832	SCREW (M6 X 25)	2		
15	87	828040	PRESSURE SWITCH	1		1
16		815004M	PLATE	1		
17	87	828039	TEMPERATURE SWITCH	1		
18	10	40011126	SCREW (M6 X 13)	1		
19	25	82069M	GROMMET	4		
20	84	825102A	HI-TENSION BOOT	4		
21	33	827858	SPARK PLUG	4		
22	339	825101	IGNITION COIL	2		
23	10	826844	SCREW (M6 X 30)	4		
24	12	40023	WASHER	4	(USE WHERE APPLICABLE)	
25	84	827350A	ENGINE WIRING HARNESS	1		
26	88	812619	FUSE	1		
27	10	821045	SCREW (M5 X 10)	1		
27	10	40011126	SCREW (M6 X 13)	1	(BIGFOOT)	
28	10	40011126	SCREW (M6 X 13)	1		
29	54	816311	STA-STRAP	AR		6
30	84	88439A	BATTERY CABLE	1	(NEGATIVE)	
31	85	79695	INSULATOR BOOT	1		
32	84	88439A	BATTERY CABLE	1	(POSITIVE)	
33		812443	RETAINER	1		
34	87	850691	SWITCH	1		3
35	84	86232A	HARNESS-AUXILIARY	1	(HANDLE)	
.	61	822775A97	POWERHEAD	1		3
.	61	822775A98	POWERHEAD	1	(BIGFOOT)	