



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		822649	EXHAUST VALVE	4		2
2		822648	INTAKE VALVE	4		2
3	12	825044	SEAT-VALVE SPRING	8		2
4	26	822647	SEAL-VALVE STEM	8		4,2
5	24	823678	VALVE SPRING-OUTER	8		2
6		822650	RETAINER-VALVE SPRING	8		2
7	28	822651	KEY	16		2
8		825045A 1	ROCKER ARM	8		2
9	10	825046	SCREW	8		2
10	11	826150	NUT	8		2
11		825049	ROCKER SHAFT	1		2
12		825050	PLATE	2		2
13		825051	PLATE	1		2
14	24	825052	SPRING	2		2
15	10	826410 30	SCREW (M8 X 30)160	5		2
16	19	825042	PLUG	2		2
-	27	832013A.96	GASKET SET	1		
-		825034A 8	CYLINDER HEAD ASSY.	1		