



101 Hot Glue (Obtain Locally)

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
24	87	18286A40	SWITCH ASSEMBLY(POWER TRIM)	1		
25		812830	PLUG (NON-POWER TRIM)	1		
26		812443	RETAINER	1		
27	22	813613	TELLTALE FITTING	1		
28		813606	SEAL	1		
29	10	40011151	SCREW	2		
30		813605	SEAL	2		2
31	32	75680	HOSE (15 IN.)	1		
32		19812A	ANCHOR BRACKET	1		
33	10	42975	DRIVE SCREW	2		
34		98889	LATCH	1		
35		39519	CUP	1		
36	84	88807A28	CABLE	1		
37	10	812832	SCREW	2		
38	10	40003 35	SCREW	1		
39	12	35280	WASHER	2		
40	13	37642	WAVE WASHER	2		
41	23	19428	BUSHING	1		
42		813547T	COWL LATCH LEVER	1	(BLACK)	
42		813547T 6	COWL LATCH LEVER	1	(GRAY)	
42		813547F 3	COWL LATCH LEVER	1	(TRACKER GRAPHITE GRAY)	
43		826354A	COWL LATCH BUSHING	1		
44		813604	LATCH CAM	1		
45	11	826833	NUT	1		
46		813939A	RELAY ASSEMBLY	1	POWER TRIM	
46		828151A	RELAY	2	POWER TRIM	2
47	10	40011130	SCREW	2	POWER TRIM	
48		812717T	TRIM COVER	1	(BLACK)	
48		812717T 6	TRIM COVER	1	(GRAY)	
48		812717F 1	TRIM COVER	1	(TRACKER GRAPHITE GRAY)	
49	10	40067 31	SCREW	4		
50		823593A	AIR DEFLECTOR KIT	1		