



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1643	6038A 5	GEAR HOUSING ASSEMBLY, CO	1	(SHORT SHAFT) UNITED STAT	
-	1643	6038A 7	GEAR HOUSING ASSEMBLY, CO	1	(LONG SHAFT) UNITED STATES	
-	1643	6038A17	GEAR HOUSING ASSEMBLY, CO	1	(SHORT SHAFT) UNITED STATI	
-	1643	6038A18	GEAR HOUSING ASSEMBLY, CO	1	(LONG SHAFT) UNITED STATES	
1	1643	6038A 6	GEAR HOUSING ASSEMBLY	1		
2	17	46912	PIN, DOWEL - GEAR HOUSIN	2		
3	16	33778	STUD	3	WATER PUMP BODY/BASE TO	
4	16	57933	STUD	2	GEAR HOUSING TO DRIVE SHA	
5	31	62091	BEARING, ROLLER - DRIVE S	1		
6		63850	SCREEN, WATER INTAKE - S	1		
6		63851	SCREEN, WATER INTAKE - P	1		
7	10	36070	SCREW	1	WATER INTAKE SCREEN TO GE	
8	11	45812	NUT, WATER INTAKE SCREEN S	1		
9		38071	PLATE, SUPPORT - EXHAUST	1		
10		37721	SEAL, EXHAUST TUBE	1		1
11	43	55607	GEAR, PINION - DRIVE SHAFT	1		
12	11	55910	NUT, PINION GEAR TO DRIVE :	1		
13	27	32771	GASKET, WATER PUMP BASE	1		1
14	25	26855	"O" RING, WATER PUMP BASE	1		1
15	46	73640A 1	WATER PUMP BASE ASSEMBL	1		
16	26	26782	OIL SEAL, WATER PUMP BA:	1		
17	26	23300	OIL SEAL, WATER PUMP BAS	1		
18	17	35973	DOWEL PIN, WATER PUMP E	2		
19	27	32769	GASKET	1	LOWER - WATER PUMP BASE T	1
20		54705	PLATE FACE	1	WATER PUMP BASE TO WATER	
21	27	32770	GASKET UPPER	1	FACE PLATE TO WATER PUMP	1
22	47	65959	IMPELLER, WATER PUMP	1		
23	28	56662	KEY, IMPELLER DRIVE	1		
24	46	48746A 1	WATER PUMP BODY ASSEMBL	1		
25		48753	INSERT, WATER PUMP BOD	1		
26	12	29245	WASHER, WATER PUMP BODY	3		
27	11	36069	NUT, WATER PUMP BODY ANC	3		
28	26	38452	SEAL, WATER PUMP BODY TO	1		1
29	12	38453	WASHER, CUPPED - WATER T	1		
30	25	20273	RING, RUBBER - CENTRIFUGAI	1		1
31	10	28634	SCREW, GREASE FILLER AND	2		
32	12	20260	WASHER, GREASE FILLER ANI	2		
35		69787A 1	SHAFT ASSEMBLY, SHIFT - LO	1	UNITED STATES 4357640 THRL	
35		76063A 1	SHAFT ASSEMBLY, SHIFT - LO	1	UNITED STATES 4576237 AND I	
36	53	29641	CLIP, RETAINING - SHIFT SH	1		
37	25	25429	"O" RING, SHIFT SHAFT RUSH	1		1