



| Parts List | | | | | | |
|------------|-------|----------|------------------------------|-----|----------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 2153 | 5392 | TOP COWL (MANUAL) | 1 | | |
| 1 | 2153 | 6055 | TOP COWL (ELECTRIC) | 1 | | |
| 2 | | 55455 | HOOK, TOP COWL LATCH - REAF | 1 | | |
| 3 | 10 | 22956 | SCREW, REAR HOOK TO TOP CO | 2 | | |
| 4 | 13 | 26992 | LOCKWASHER, REAR HOOK MO | 2 | | |
| 5 | | 37690 | SHIELD, REAR - TOP COWL | 1 | | |
| 6 | 10 | 37370 | SCREW, REAR SHIELD TO TOP | 3 | | |
| 7 | 13 | 37371 | LOCKWASHER, REAR SHIELD SI | 3 | | |
| 8 | | 55459A 5 | RETAINER ASSEMBLY, TOP COV | 1 | | |
| 9 | | 35496 | PAD, BUMPER - TOP COWL RE | 1 | | |
| 10 | 10 | 24234 | SCREW, RETAINER TO TOP COV | 1 | | |
| 11 | 13 | 39107 | LOCKWASHER, RETIANER TO TI | 1 | | |
| 12 | | 52737 | LEVER, COWL LATCH HINGE | 1 | | |
| 13 | | 52739 | HINGE, COWL LATCH - TOP COW | 1 | | |
| 14 | 17 | 58998 | PIN, COWL LATCH LEVER TO HIP | 1 | | |
| 15 | 25 | 20116 | GROMMET, CHOKE KNOB - TOP | 1 | | |
| 16 | | 72020 | BRACKET, REAR COWL SUPPOF | 1 | | |
| 18 | | 60577 | MOUNT, RUBBER - REAR SUPPC | 2 | | |
| 19 | 12 | 21631 | WASHER, REAR SUPPORT BRAI | AR | | 3 |
| 20 | 11 | 29598 | NUT, REAR SUPPORT BRACKET | 2 | | |
| 21 | | 88043A 5 | BRACKET ASSEMBLY, FRONT SL | 1 | | |
| 22 | | 31014 | MOUNT, RUBBER - FRONT SUPP | 2 | | |
| 23 | 13 | 26992 | LOCKWASHER | 2 | FRONT SUPPORT BRACKET RI | |
| 24 | 11 | 29598 | NUT, FRONT SUPPORT BRACKE | 2 | | |
| 25 | 10 | 37562 | SCREW | 2 | FRONT SUPPORT BRACKET TO | |
| 26 | | 58124A20 | SWITCH ASSEMBLY, MERCURY | 1 | | |
| 27 | 10 | 69235 | SCREW, SWITCH TO FRONT BR | 1 | | |
| 28 | | 45915 | TERMINAL BLOCK | 1 | | |
| 29 | 10 | 20411 | SCREW | 1 | TEMPRINAL BLOCK TO FRONT B | |
| 30 | 10 | 69079 | SCREW, HARNESS LEADS ATTA | 1 | | |
| 31 | 17 | 36242 | ROLL PINE, MERCURY SWITCH | 2 | | |
| 32 | 87 | 74605A 4 | SWITCH ASSEMBLY | 1 | NEUTRAL START USE WITH TI | |
| 33 | 10 | 64332 | SCREW, SWITCH TO FRONT BR | 2 | | |
| 34 | 11 | 24832 | NUT, SWITCH SCREW | 2 | | |
| 35 | | 88044 | ACTUATOR, INTERLOCK | 1 | | |
| 36 | 24 | 88099 | SPRING, INTERLOCK ACTUATO | 1 | | |
| 37 | 10 | 37892 | SCREW, ACTUATOR TO FRONT | 1 | | |
| 38 | 12 | 22887 | WASHER, ACTUATOR SCREW | 1 | | |
| 39 | 23 | 88100 | SPACER, ACTUATOR SCREW | 1 | | |
| 40 | 11 | 45812 | NUT, ACTUATOR SCREW | 1 | | |