



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	394	2271A 2	MAGNETO ASSEMBLY, COMPLE	1,1		
2	45	27951	SHAFT, MAGNETO DRIVE	1,1		
-		29321A 7	MAGNETO ADAPTOR AND PILOT	1,1		
3		29321A 1	MAGNETO ADAPTOR AND PILOT	1,1		
4	30	20066	BEARING, BALL - MAGNETO PILC	1,1		
5	24	27944	SPRING, HORSESHOE - MAGNET	1,1		
6	17	27962	PIN, ANCHOR - HORSESHOE SPR	1,1		
7	12	29245	WASHER, HORSESHOE SPRING	1,1		
8		27946A 1	ECONOMISER COLLAR AND PIN	1,1		
9	17	27961	PIN, ECONOMISER COLLAR - SP	1,1		
10	22	25094	FITTING, GREASE - MAGNETO AI	1,1		
11		29557A 1	THROTTLE ACTUATOR ASSEMB	1,1		
12	23	26602	BUSHING, NYLON-THROTTLE AC	1,1		
13	10	32078	SCREW, THROTTLE ACTUATOR	2,2		
14		27947	SWIVEL, LINKAGE - ECONOMISE	1,1		
15		25996A 1	SWIVEL AND LINK ROD ASSEMB	1,1		
16		30043	ADAPTOR, MAGNETO	1,1		
17	22	25094	FITTING, GREASE - MAGNETO AI	1,1		
18	12	27939	WASHER, MAGNETO PILOT	1,1		
19	14	27960	TAB WASHER, ADAPTOR CAP FA	1,1		
20	13	27959	WASHER, WAVE - MAGNETO BA	1,1		
21		27955	CAP, MAGNETO ADAPTOR AND	1,1		
22	10	30110	SCREW, ADAPTOR AND PILOT T	4,4		
23	10	22040	SCREW, ADAPTOR AND PILOT T	3,3		
24	12	20084	WASHER, ADAPTOR AND PILOT	3,3		
25	11	20083	NUT, ADAPTOR AND PILOT TO C	3,3		
26		29277	PLATE, THROTTLE STOP	1,1		
27	37	29315	DECAL, THROTTLE STOP PLATE	1,1		
28	10	24933	SCREW, THROTTLE STOP ADJU	3,3		
29	11	20088	NUT, THROTTLE STOP ADJUSTI	3,3		
30		26852	CAP, NYLON - ADJUSTING SCRE	3,3		
31	10	29197	SCREW, THROTTLE STOP PLAT	2,2		
32	28	28657	KEY, MAGNETO DRIVING	1,1		
33		29784	HUB, DRIVEN PULLEY	1,1		
34		29783A 1	DRIVEN PULLEY ASSEMBLY	1,1		
35	17	24873	ROLL PIN, FLANGE LOCATING	1,1		
36		29785	FLANGE, DRIVEN PULLEY	1,1		
37	12	20138	WASHER, PULLEY CLAMPING SC	1,1		
38	10	29240	SCREW, PULLEY CLAMPING	1,1		
39		20140	BELT, TIMING	1,1		
40		27949	RUD LINK UPPER	1,1		