



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1554	2489A 2	DRIVE SHAFT HOUSING ASSEM	1,1		
1	1564	2772A 1	DRIVE SHAFT HOUSING ASSEM	1,1		
2	16	32028	STUD, DRIVE SHAFT HOUSING	1,1		
3	16	29079	STUD, DRIVE SHAFT HOUSING	1,1		
4	19	32298	PLUG, PLASTIC - WATER PICK-U	1,1		
5	11	22178	NUT, GEAR HOUSING TO DRIVE	2,2		
6		28470	ROD, PUSH - REVERSE LOCK (S)	1,1		
6		45678	ROD, PUSH - REVERSE LOCK (L)	1,1		
7	18	25191	COTTER PIN, PUSH ROD TO REV	1,1		
8	24	25122	SPRING, TENSION - PUSH ROD	1,1		
9	17	24887	PIN, REVERSE LOCK LEVER	1,1		
10		25140	LEVER, REVERSE LOCK	1,1		
11	22	21290	PLUG, GREASE - REVERSE LOCK	1,1		
12		35474	COVER, LOWER MOUNT CLAMP	2,2		
13	10	29722	SCREW, COVER TO LOWER MO	2,2		
14	11	35521	NUT, LOWER MOUNT CLAMP CC	2,2		
15		35473	CLAMP, LOWER MOUNT TO DRP	2,2		
16	10	29256	SCREW, LOWER MOUNT CLAMP	4,4		
17	24	35522	SPRING, TENSION - LOWER MO	4,4		
18		37395	MOUNT, RUBBER - LOWER	2,2		
19		25067	BUMPER, RUBBER - LOWER MO	2,2		
20	10	30452	SCREW, LOWER MOUNT (5 1/2"	2,2		
21	12	28051	WASHER, LOWER MOUNT SCRE	2,2		
22	12	28053	WASHER, RUBBER - LOWER MO	2,2		
23	12	30119	WASHER, LOWER MOUNT SCRE	2,2		
24	11	25096	NUT, LOWER MOUNT SCREW	2,2		
25		37394	MOUNT, RUBBER - UPPER	2,2		
26		24929	PACKING, "U" CUP - UPPER MOL	2,2		
27		24935	COVER, UPPER MOUNT - OUTSII	2,2		
28		31120	COVER, UPPER MOUNT - INSIDE	2,2		
29	10	28772	SCREW, UPPER MOUNT COVER	4,4		
30	10	31114	SCREW, UPPER MOUNT COVER	4,4		
31	11	46886	NUT, UPPER MOUNT COVER FA	8,8		
32	12	30520	WASHER, UPPER MOUNT BOLT	2,2		
33	12	30521	WASHER, RUBBER - UPPER MO	2,2		
34	12	30519	WASHER, UPPER MOUNT BOLT	2,2		
35	11	23161	NUT, UPPER MOUNT BOLT	2,2		
36	27	38501	GASKET, EXHAUST EXTENSION	1,1		4
37	11	25594	NUT, POWERHEAD TO DRIVE SH	8,8		
38		37720	TUBE, EXHAUST (SHORT SHAFT	1,1		
38		45681	TUBE, EXHAUST (LONG SHAFT)	1,1		