



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1333	3298	CARBURETOR ASSEMBLY, COMI	2,2,		
1	1333	3709	CARBURETOR ASSEMBLY, COMI	,2,2		
2	1399	110A 1	FLOAT ASSEMBLY	2,2,2,2		
3			PIN, FLOAT LEVER PINION	4,4,4,4		
4			LEVER, FLOAT (LOWER)	2,2,2,2		
5			LEVER, FLOAT (UPPER)	2,2,2,2		
6	1399	1473	INLET NEEDLE, SEAT AND GA	2,2,2,2		
7			GASKET, INLET SEAT	2,2,2,2		
8			GASKET, FLOAT BOWL COVER	2,2,2,2		
9	1399	1133	COVER, FLOAT BOWL	2,2,2,2		
10	10	20854	SCREW, FLOAT BOWL COVER	2,2,,		
11	10	25850	SCREW, FLOAT BOWL COVER	2,2,,		
10	10	52195	SCREW, FLOAT BOWL COVER	,,2,2		
11	10	52196	SCREW, FLOAT BOWL COVER	,,2,2		
12	13	52197	LOCKWASHER, FLOAT BOWL C	,,4,4		
13			GASKET, STRAINER COVER (L	2,2,2,2		
14	1399	1754	SCREEN FILTER	2,2,2,2		
15			GASKET, STRAINER COVER (S	2,2,2,2		
16	1399	1135	COVER, STRAINER	2,2,2,2		
17			GASKET, STRAINER COVER SC	2,2,2,2		
18	10	25822	SCREW, STRAINER COVER FA	2,2,2,2		
19	10	20847	SCREW, THROTTLE STOP LEV	2,2,2,2		
20	1399	97	LEVER, THROTTLE STOP (SEE	2,2,2,2		
21	1399	2012	SHAFT, THROTTLE	2,2,2,2		
22			TUBE, IDLE	2,2,2,2		
23			GASKET, IDLE TUBE	2,2,2,2		
24			SCREW AND LOCKWASHER, T	4,4,4,4		
25	1399	3392	SHUTTER, THROTTLE	2,2,2,2		
26			SPRING, IDLE ADJUSTMENT S	2,2,2,2		
27	1399	1713	SCREW, IDLE ADJUSTMENT	2,2,2,2		
28	10	28405	SCREW, PLUG - MAIN FUEL JE	2,2,2,2		
29			GASKET, JET CHANNEL PLUG	2,2,2,2		
30	1399	1467	JET, MAIN FUEL (.067)	OPT.,0		
30	1399	1465	JET, MAIN FUEL (.065)	OPT.,0		
30	1399	1463	JET, MAIN FUEL (.063) - STAND	2,2,2,2		
30	1399	1461	JET, MAIN FUEL (.061)	OPT.,0		
30	1399	1459	JET, MAIN FUEL (.059)	,,OPT.,		
31			GASKET, MAIN FUEL JET	2,2,2,2		
32			NOZZLE, MAIN	2,2,2,2		
33	10	23178	SCREW, PLUG - MAIN NOZZLE	2,2,2,2		
34			SPRING, THROTTLE SHAFT RE	1,1,1,1		