



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	393	2799A19	DISTRIBUTOR ASSEMBLY, COM	1	
2		45391	SPACER, IGNITION WIRE	1	
3	33	45191	SPARK PLUG (CHAMPION - L19V	4	
4		30109	GROUND STRAP, DISTRIBUTOR	1	
5	10	26548	SCREW, DISTRIBUTOR GROUND	1	
6		26551	BRACKET, TAB - CRANKCASE SC	1	
7	45	47953	DRIVE SHAFT, DISTRIBUTOR	1	
8		46242A	PILOT ASSEMBLY, DISTRIBUTOR	1	
9	10	48291	SCREW, DISTRIBUTOR PILOT T	4	
10	24	27944	SPRING, HORSESHOE	1	
11	17	27962	PIN, SPRING TERMINAL	1	
12		48103A	ECONOMIZER COLLAR AND PIN	1	
13	17	27961	PIN, SPRING RETAINER	1	
14	22	25094	FITTING, GREASE - ECONOMIZEI	1	
15		38230A	THROTTLE ACTUATOR ASSEMB	1	
16	23	26602	BUSHING, NYLON - THROTTLE	1	
17	10	46420	SCREW, THROTTLE ACTUATOR	2	
18	12	46246	WASHER, DISTRIBUTOR PILOT	1	
19		30043A	ADAPTOR, DISTRIBUTOR	1	
20	10	22040	SCREW, ADAPTOR AN PILOT TO	3	
21	12	20084	WASHER, ADAPTOR AND PILOT	3	
22	11	20083	NUT, ADAPTOR AND PILOT TO C	3	
23	22	25094	FITTING, GREASE - DISTRIBUTO	1	
24	12	27939	WASHER, THRUST - DISTRIBUT	1	
25	30	20066	BEARING, BALL - DISTRIBUTOR	1	
26	14	27960	TAB WASHER, CAP LOCKING	1	
27	13	27959	WASHER, WAVE - TAB WASHER	1	
28		27955	CAP, ADAPTOR AND PILOT FAST	1	
29	23	29909	SPACER, DRIVEN PULLEY	1	
30		29906A	DRIVEN PULLEY ASSEMBLY	1	
31	17	29908	PIN, DRIVEN PULLEY	1	
32		29907	FLANGE, DRIVEN PULLEY	1	
33	28	29910	KEY, DISTRIBUTOR DRIVING	1	
34	10	29911	SCREW, PULLEY CLAMPING	1	
35	13	26996	LOCKWASHER, PULLEY CLAMPI	1	
36		20140	BELT, TIMING	1	
37		46251	PLATE, THROTTLE STOP	1	
38	23	48456	SPACER, THROTTLE PLATE TO	1	
39	10	31299	SCREW, THROTTLE STOP PLAT	2	
40	10	46311	SCREW, THROTTLE STOP ADJU	2	
40	10	21504	SCREW, THROTTLE STOP ADJU	1	