



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1626	3238A 4	GEAR HOUSING ASSEMBLY, COI	1,1,,		
-	1626	3238A 5	GEAR HOUSING ASSEMBLY, COI	1,1,,		
-	1626	3688A 4	GEAR HOUSING ASSEMBLY, COI	,,1,1		
-	1626	3688A 5	GEAR HOUSING ASSEMBLY, COI	,,1,1		
1	1626	3238A 1	GEAR HOUSING ASSEMBLY (AI	1,1,,		
1	1626	3502A 1	GEAR HOUSING ASSEMBLY (PI	,,1,1		
1	1626	3688A 1	GEAR HOUSING ASSEMBLY (PI	,,1,1		
2	16	37728	STUD, WATER PUMP BODY	3,3,3,3		
3	16	52662	STUD, GEAR HOUSING TO D	2,2,2,2		
4	31	20231	BEARING, ROLLER - DRIVE S	1,1,1,1		
5		38071	PLATE, SUPPORT - EXHAUST	1,1,1,1		
6		37721	SEAL, EXHAUST TUBE	1,1,1,1		
7	43	20834	GEAR, PINION - DRIVE SHAFT	1,1,1,1		
8	10	20925	SCREW, PINION GEAR TO DRIP	1,1,1,1		
9	14	29163	TAB WASHER, PINION GEAR S	1,1,1,1		
7	43	46373	GEAR, PINION - DRIVE SHAFT	,,1,1		
10	11	30932	NUT, PINION GEAR TO DRIVE	,,1,1		
11	27	32771	GASKET, WATER PUMP BASE	1,1,1,1		
12	25	26855	"O" RING, WATER PUMP BASE	1,1,1,1		
13	46	39531A 1	WATER PUMP BASE ASSEMBL	1,1,,		
13	46	48745A 1	WATER PUMP BASE ASSEMBL	,,1,1		
14	26	26782	OIL SEAL, WATER PUMP BAS	1,1,1,1		
15	26	23300	OIL SEAL, WATER PUMP BAS	1,1,1,1		
16	17	35973	DOWEL PIN, WATER PUMP E	2,2,2,2		
17	27	32769	GASKET, LOWER - WATER PUI	1,1,1,1		
18		32768	PLATE, FACE - WATER PUMP E	1,1,1,1		
19	27	32770	GASKET, UPPER - FACE PLATE	1,1,1,1		
20	47	20268	IMPELLER, WATER PUMP	1,1,1,1		
21	17	23733	PIN, IMPELLER DRIVE	1,1,1,1		
22	46	32767A 1	WATER PUMP BODY ASSEMBL	1,1,,		
22	46	48746A 1	WATER PUMP BODY ASSEMBL	,,1,1		
23		32001	INSERT, WATER PUMP BODY	1,1,,		
23		48753	INSERT, WATER PUMP BODY	,,1,1		
24	26	32121	OIL SEAL, WATER PUMP BOI	1,1,1,1		
25	13	26992	LOCKWASHER, WATER PUMP	3,3,,		
26	11	29598	NUT, WATER PUMP BODY ANI	3,3,,		
25	12	38753	WASHER, WATER PUMP BODY	,,3,3		
26	11	35045	NUT, WATER PUMP BODY ANI	,,3,3		
27	26	38452	SEAL, WATER PUMP BODY TO	1,1,1,1		
28	12	38453	WASHER, CUPPED - WATER T	1,1,1,1		
29	25	20272	RING, RUBBER, CENTRIFUGAL	1,1,1,1		